HT-C9930

3.1CH Blu-ray Home Cinema System

user manual

imagine the possibilities

Thank you for purchasing this Samsung product.
To receive more complete service,
please register your product at
www.samsung.com/register

SAMSUNG

HT-C9930_ELS_0914.indd 1 2010-09-14 6:50:44

Safety Information

Safety Warnings

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER(OR BACK).
NO USER-SERVICEABLE PARTS ARE INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

		
This symbol indicates "dangerous voltage" inside the product that presents a risk of electric shock or personal injury.	**CAUTION** : TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.	This symbol indicates important instructions accompanying the product.

WARNING

- To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

CAUTION

- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- The Mains plug is used as a disconnect device and shall stay readily operable at any time.
- This apparatus shall always be connected to a AC outlet with a protective grounding connection.
- To disconnect the apparatus from the mains, the plug must be pulled out from the mains socket, therefore the mains plug shall be readily operable.

CLASS 1	**LASER PRODUCT**
KLASSE 1	**LASER PRODUKT**
LUOKAN 1	**LASER LAITE**
KLASS 1	**LASER APPARAT**
PRODUCTO	**LÁSER CLASE 1**

CLASS 1 LASER PRODUCT

This Compact Disc player is classified as a CLASS 1 LASER product.
Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION

- INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED, AVOID EXPOSURE TO BEAM.

Wiring the Main Power Supply Plug (UK Only)

IMPORTANT NOTICE
The mains lead on this equipment is supplied with a moulded plug incorporating a fuse. The value of the fuse is indicated on the pin face of the plug and if it requires replacing, a fuse approved to BS1362 of the same rating must be used. Never use the plug with the fuse cover removed. If the cover is detachable and a replacement is required, it must be of the same colour as the fuse fitted in the plug. Replacement covers are available from your dealer. If the fitted plug is not suitable for the power points in your house or the cable is not long enough to reach a power point, you should obtain a suitable safety approved extension lead or consult your dealer for assistance. However, if there is no alternative to cutting off the plug, remove the fuse and then safely dispose of the plug. Do not connect the plug to a mains socket as there is a risk of shock hazard from the bared flexible cord. Never attempt to insert bare wires directly into a mains socket. A plug and fuse must be used at all times.

IMPORTANT
The wires in the mains lead are coloured in accordance with the following code:– BLUE = NEUTRAL BROWN = LIVE As these colours may not correspond to the coloured markings identifying the terminals in your plug, proceed as follows:–The wire coloured BLUE must be connected to the terminal marked with the letter N or coloured BLUE or BLACK. The wire coloured BROWN must be connected to the terminal marked with the letter L or coloured BROWN or RED.

WARNING : DO NOT CONNECT EITHER WIRE TO THE EARTH TERMINAL WHICH IS MARKED WITH LETTER E OR BY THE EARTH SYMBOL ⏚, OR COLOURED GREEN OR GREEN AND YELLOW.

HT-C9930_ELS_0914.indd 2 2010-09-14 6:51:23

Precautions

- Ensure that the AC power supply in your house complies with the identification sticker located on the back of your product.
- Install your product horizontally, on a suitable base (furniture), with enough space around it for ventilation (7.5~10cm).
- Do not place the product on amplifiers or other equipment which may become hot. Make sure the ventilation slots are not covered.
- Do not stack anything on top of the product.
- Before moving the product, ensure the Disc Insert Hole is empty.
- In order to disconnect the product completely from the power supply, remove the main plug from the wall outlet, especially when left unused for a long period of time.
- During thunderstorms, disconnect the AC main plug from the wall outlet. Voltage peaks due to lightning could damage the product.
- Do not expose the product to direct sunlight or other heat sources. This could lead to overheating and malfunction of the product.
- Protect the product from moisture, and excess heat or equipment creating strong magnetic or electric fields (i.e. speakers.).
- Disconnect the power cable from the AC supply if the product malfunctions.
- Your product is not intended for industrial use. Use of this product is for personal use only.
- Condensation may occur if your product or disc has been stored in cold temperatures. If transporting the product during the winter, wait approximately 2 hours until the product has reached room temperature before using.
- The batteries used with this product contain chemicals that are harmful to the environment. Do not dispose of batteries in the general household trash.

Viewing TV using the 3D function

IMPORTANT HEALTH AND SAFETY INFORMATION FOR 3D PICTURES. Read and understand the following safety information before using the TV's 3D function.

WARNING

- Some viewers may experience discomfort while viewing 3D TV such as dizziness, nausea and headaches. If you experience any such symptom, stop viewing 3D TV, remove 3D Active Glasses and rest.
- Watching 3D images for an extended period of time may cause eye strain. If you feel eye strain, stop viewing 3D TV, remove your 3D Active Glasses and rest.
- A responsible adult should frequently check on children who are using the 3D function. If there are any reports of tired eyes, headaches, dizziness, or nausea, have the child stop viewing 3D TV and rest.
- Do not use the 3D Active Glasses for other purposes (such as general eyeglasses, sunglasses, protective goggles, etc.)
- Do not use the 3D function or 3D Active Glasses while walking or moving around. Using the 3D function or 3D Active Glasses while moving around may result in injuries due to running into objects, tripping, and/or falling.

HT-C9930_ELS_0914.indd 3 2010-09-14 6:51:23

Safety Information

Cautions on Handling and Storing Discs

Small scratches on the disc may reduce sound and picture quality or cause skipping.

Be especially careful not to scratch discs when handling them.

Holding discs

- Do not touch the playback side of the disc.
- Hold the disc by the edges so that fingerprints will not get on the surface.
- Do not stick paper or tape on the disc.



Disc Storage

- Do not keep in direct sunlight
- Keep in a cool ventilated area
- Keep in a clean Protection jacket.
  Store vertically.

NOTE

- Do not allow the discs to become contaminated with dirt.
- Do not load cracked or scratched discs.

Handling and Storing Discs

If you get fingerprints or dirt on the disc, clean it with a mild detergent diluted in water and wipe with a soft cloth.

- When cleaning, wipe gently from the inside to the outside of the disc

NOTE

- Condensation may form if warm air comes into contact with cold parts inside the product. When condensation forms inside the product, it may not operate correctly. If this occurs, remove the disc and let the product stand for 1 or 2 hours with the power on.

Licence

- ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX,Inc. This is an official DivX Certified device that plays DivX video. Visit www. divx.com for more information and software tools to convert your files into DivX video.
  ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play DivX Video-on-Demand (VOD) content. To generate the registration code, locate the DivX VOD section in the device setup menu. Go to vod.divx.com with this code to complete the registration process and learn more about DivX VOD.
  DivX Certified to play DivX video up to HD 1080p, including premium content.
- **iPod is a trademark of Apple Inc., registered in the U.S. and other countries.**
  iPhone is a trademark of Apple Inc.
- < Open Source Licence Notice >
  In the case of using open source software, Open Source Licences are available on the product menu.
- "Blu-ray 3D" and "Blu-ray 3D"logo are trademarks of Blu-ray Disc Association.

Copyright

© 2010 Samsung Electronics Co., Ltd. All rights reserved.

HT-C9930_ELS_0914.indd 4 2010-09-14 6:51:24

Contents

SAFETY INFORMATION 2

2 Safety Warnings
3 Precautions
4 Cautions on Handling and Storing Discs
4 Licence
4 Copyright

GETTING STARTED 7

7 Icons that will be used in manual
8 Disc Types and Characteristics
12 Accessories
14 Description
14 Front Panel
15 Rear Panel
16 Rear Panel of the Subwoofer
17 Remote control
19 Installation

CONNECTIONS 22

22 Connecting the Speakers
27 Connecting External Devices/your TV via HDMI
28 Connecting the FM Antenna
28 Attaching the Toroidal Ferrite Core to the Speaker Cable
29 Connecting Audio from External Components
30 Connecting to the Network

SETUP 32

32 Before Starting (Initial settings)
33 Setting the Menu
34 Display
34 3D
35 TV Aspect
35 BD Wise
35 Resolution
37 HDMI Format
37 Movie Frame (24Fs)
37 Progressive Mode
37 Still Mode
37 HDMI Deep Color
38 Audio
38 Speaker Setting
39 EQ Optimizer
39 HDMI Audio
39 Digital Output
40 Dynamic Range Control
40 AV Sync
40 Audio Return Channel
41 System
41 Initial Settings
41 Internet@TV Screen Size
41 Anynet+ (HDMI-CEC)
41 BD Data Management
42 Clock
42 DivX(R) Registration
42 DivX(R) Deactivation
43 Network
43 Network Settings
46 Network Status
46 BD-Live Internet Connection
46 Language
47 Security
47 Parental Rating
47 Change Password

HT-C9930_ELS_0914.indd 5 2010-09-14 6:51:24

Contents

SETUP 47

47 General
47 Background
47 Front Display
47 Power On/Off Sound
48 Support
48 Software Upgrade
48 Contact Samsung

BASIC FUNCTIONS 49

49 Playing a Disc
49 Using the Disc menu / Title menu / Popup menu
50 Using the Search and Skip Functions
51 Slow Motion Play/Step Motion Play
51 Repeat Playback
52 Using the TOOLS button
54 Listening to Music
56 Sound Mode
57 Playing back a Picture
58 Playing back a USB Storage
59 Listening to Radio
59 Use iPod/iPhone with a Wireless Dock Cradle for iPod/iPhone
60 How to Link the Wireless Transmitter with the Main Unit

NETWORK SERVICES 62

62 Using Internet@TV
66 BD-LIVE™
66 Software Upgrade Notification
66 Using the AllShare Function

OTHER INFORMATION 68

68 Troubleshooting
71 Specifications

- Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance.
- An administration fee may be charged if either
  a. an engineer is called out at your request and there is no defect in the product (i.e. where you have failed to read this user manual)
  b. you bring the unit to a repair centre and there is no defect in the product (i.e. where you have failed to read this user manual).
- The amount of such administration charge will be advised to you before any work or home visit is carried out.

HT-C9930_ELS_1025.indd 6 2010-10-25 12:42:35

Getting Started

Icons that will be used in manual

Make sure to check the following terms before reading the user manual.

Term	Logo	Icon	Definition
BD-ROM			This involves a function available on a BD-ROM.
BD-RE/-R			This involves a function available on a BD-RE/-R disc recorded in the BD-RE format.
DVD-VIDEO			This involves a function available on a DVD-VIDEO.
DVD-RW(V)			This involves a function available on recorded DVD+RW or DVD-RW(V)/ DVD-R/+R discs that have been recorded and finalsed.
DVD-R			
DVD+RW			
DVD+R			
Audio CD			This involves a function available on an audio CD-RW/-R (CD-DA format).
MP3 WMA	-		This involves a function available in a CD-RW/-R, DVD-RW/-R disc or a USB storage media containing MP3 or WMA contents.
JPEG	-		This involves a function available in a CD-RW/-R, DVD-RW/-R disc or a USB storage media containing JPEG contents.
DivX MKV MP4	 DivX		This involves a function available in a CD-RW/-R, DVD-RW/-R disc or a USB storage media containing DivX contents.
USB storage device	-		This involves a function available on a USB storage device.
CAUTION	-		This involves a situation where a function does not operate or settings may be cancelled.
NOTE	-		This involves tips or instructions on the page that help each function operate.
Shortcut Key	-		This function provides direct and easy access pressing the button on the remote control.

- This product is compatible with the PAL colour system only.
- NTSC discs will not play.

HT-C9930_ELS_0914.indd 7 2010-09-14 6:51:25

Disc Types and Characteristics

Blu-ray Disc Compatibility

Blu-ray is a new and evolving format. Accordingly, disc compatibility issues are possible. Not all discs are compatible and not every disc will play back. For additional information, refer to the Disc Types and Characteristics section of this Manual. If you encounter compatibility problems, please contact the SAMSUNG customer care centre.

NOTE

- Playback may not work for some types of discs, or when specific operations, such as angle change and aspect ratio adjustment, are being performed. Information about the discs is written in detail on the box. Please refer to this if necessary.
- Do not allow the disc to become dirty or scratched. Fingerprints, dirt, dust, scratches or deposits of cigarette smoke on the recording surface may make it impossible to use the disc for playback.
- When a BD-Java title is played, loading may take longer than a normal title, or some functions may perform slowly.

Discs that cannot be played

- HD DVD Disc
- DVD-RAM
- 3.9 GB DVD-R Disc for Authoring.
- DVD-RW(VR mode)
- Super Audio CD(except CD layer)
- DVD-ROM/PD/MV-Disc, etc CVD/CD-ROM/ CDV/CD-G/CD-I/LD
- CDGs play audio only, not graphics.

NOTE

- Some commercial discs and DVD discs purchased outside your region may not be playable with this product. When these discs are played, “Cannot read this disc. Please check the regional code of the disc.” will be displayed.
- If a DVD-R/-RW disc has not been recorded properly in DVD video format, it will not be playable.

Logos of Discs that can be played

Blu-ray Disc	3D Blu-ray Disc
Dolby Digital Plus	PAL broadcast system in U.K, France, Germany, etc.
Dolby TrueHD	DTS-HD High Resolution Audio
Java	DTS-HD Master Audio | Essential
BD-LIVE	

HT-C9930_ELS_0914.indd 8 2010-09-14 6:51:26

Region code

Both the product and the discs are coded by region. These regional codes must match in order to play the disc. If the codes do not match, the disc will not play.

Disc Type	Region Code	Area
Blu-ray		North America, Central America, South America, Korea, Japan, Taiwan, Hong Kong and South East Asia.
		Europe, Greenland, French territories, Middle East, Africa, Australia and New Zealand.
		India, China, Russia, Central and South Asia.
DVD-VIDEO		The U.S., U.S. territories and Canada
		Europe, Japan, the Middle East, Egypt, South Africa, Greenland
		Taiwan, Korea, the Philippines, Indonesia, Hong Kong
		Mexico, South America, Central America, Australia, New Zealand, Pacific Islands, Caribbean
		Russia, Eastern Europe, India, most of Africa, North Korea, Mongolia
		China

Disc Types

BD-ROM

Blu-ray Disc Read Only Memory. A BD-ROM disc contains pre-recorded data. Although a BD-ROM may contain any form of data, most BD-ROM discs will contain movies in High Definition format, for playback on the product. This product can play back pre-recorded commercial BD-ROM discs.

BD-RE/BD-R

Blu-ray Disc Rewritable/Blu-ray Disc Recordable. BD-RE/BD-R is the ideal format for making backups, or recording personal video.

DVD-VIDEO

- A digital versatile disc (DVD) can contain up to 135-minutes of images, 8 audio languages and 32 subtitle languages. It is equipped with MPEG-2 picture compression and Dolby Digital surround, allowing you to enjoy vivid and clear quality images.
- When switching from the first layer to the second layer of a dual-layered DVD Video disc, there may be momentary distortion in the image and sound. This is not a malfunction of the product.
- Once a DVD-RW/-R recorded in Video Mode is finalsed, it becomes DVD-Video. Pre-recorded (pre-stamped) commercial DVDs with movies are also referred to as DVD-Videos. This product can play back pre-recorded commercial DVD discs (DVD-Video discs) with movies.

DVD-R/-RW

- Once a DVD-R/-RW recorded in Video Mode is finalsed, it becomes DVD-Video. Ability to play back may depend on recording conditions.
- This product can play back DVD-R disc recorded and finalsed with a Samsung DVD video recorder.
- Playback can be perfomed with DVD-RW discs in the Video Mode and finalsed only.

DVD+RW

- This product can play back a DVD+RW disc recorded with a DVD Video recorder. Ability to play back may depend on recording conditions.

DVD+R

- This product can play back a DVD+R disc recorded and finalsed with a DVD Video recorder. Ability to play back may depend on recording conditions.

HT-C9930_ELS_0914.indd 9 2010-09-14 6:51:27

Audio CD

- An audio disc on which 44.1kHz PCM Audio is recorded.
- This product can play back CD-DA format audio CD-R and CD-RW discs.
- The product may not be able to play some CD-R or CD-RW discs due to the condition of the recording.

CD-R/-RW

- Use a 700MB(80 minutes) CD-R/-RW disc. If possible, do not use a 800MB(90 minutes) or above disc, as the disc may not play back.
- If the CD-R/-RW disc was not recorded as a closed session, you may experience delays when playing back the beginning of the disc or all recorded files may not play.
- Some CD-R/-RW discs may not be playable with this product, depending on the device which was used to burn them. For contents recorded on CD-R/-RW media from CDs for your personal use, playability may vary depending on contents and discs.

Disc Format

Using MP3 disc

- CD-R/-RW, DVD-RW/-R recorded with UDF, ISO9660 or JOLIET format can be played back.
- Only MP3 files with the ".mp3" or ".MP3" extension can be played.
- Playable bit rate range is from 56 Kbps to 320 Kbps.
- Playable sample-rate is 32KHz to 48KHz.
- The product can handle a maximum of 1500 files and folders under a parent folder. For MP3 files recorded with a VBR(Variable Bit Rates), the sound may cut in and out.

Using JPEG disc

- CD-R/-RW, DVD-RW/-R recorded with UDF, ISO9660 or JOLIET format can be played back.
- Only JPEG files with the ".jpg", ".JPG", ".jpeg" or "JPEG" extension can be displayed.
- Progressive JPEG is supported.

DVD-RW/-R (V)

- This is a format that is used for recording data on a DVD-RW or DVD-R disc. The disc can be played by this product once it has been finalsed.
- If a disc that has been recorded in Video Mode by a different maker's recorder but has not been finalsed, it cannot be played by this product.

DivX(Digital Video Express)

DivX is a video file format developed by Microsoft and is based on MPEG4 compression technology to provide audio and video data over the Internet in real-time.

MPEG4 is used for video encoding and MP3 for audio encoding so that the users can watch a movie at near DVD-quality video and audio.

Supported Formats(DivX)

This product only supports the following media formats. If both video and audio formats are not supported, the user may experience problems such as broken images or no sound.

Supported Video Formats

Format	Supported Versions
AVI	DivX3.11~DivX5.1, XviD

Supported Audio Formats

Format	Bit Rate	Sampling Frequency
MP3	80~384kbps	44.1khz
AC3	128~384kbps	44.1/48khz
DTS	1.5Mbps	44.1khz

- DivX files, including audio and video files, created in the DTS format can only support up to 6Mbps.
- Aspect Ratio : Although the default DivX resolution is 640x480 pixels (4:3), this product supports up to 800x600 pixels (16:9). TV screen resolutions higher than 800 will not be supported.
- When you play a disc whose sampling frequency is higher than 48khz or 320kbps, you may experience shaking on the screen during playback.
- Qpel and gmc is not supported.

MKV, MP4

- CD-R/-RW, DVD-R/-RW, USB, PC streaming
- Video Files with the following extensions can be played. : .avi, .divx, .mkv, .mp4, .AVI, .DIVX, .MKV, .MP4

NOTE

- Some DivX, MKV and MP4 format discs may not play, depending on the video resolution and frame rate condition.

HT-C9930_ELS_0914.indd 10 2010-09-14 6:51:28

Supported File Formats

Video File Support

File Extension	Container	Video Codec	Audio Codec	Resolution
*.avi	AVI	Divx 3.11/4.x/5.1/6.0	MP3 AC3 DTS WMA PCM	1920x1080
		XviD		1920x1080
		MP4v3		1920x1080
		H.264 BP/MP/HP		1920x1080
*.mkv	MKV	VC-1 AP	MP3 AC3 DTS	1920x1080
		DivX 5.1/6.0		1920x1080
		XviD		1920x1080
		H.264 BP/MP/HP		1920x1080
*.wmv	WMV (wmv9)	VC-1 AP	WMA	1920x1080
		VC-1 SM		1920x1080
*.mp4	MP4	MP4 (mp4v)	AAC	1920x1080
		H.264 BP/MP/HP		1920x1080
*.mpg *.mpeg	PS	MPEG1	MP1, 2 AC3 DTS	1920x1080
		MPEG2		1920x1080
		H.264 BP/MP/HP		1920x1080

Music File Support

File Extension	Container	Audio Codec	Support Range
*.mp3	MP3	MP3	-
*.wma	WMA	WMA	Compliant with WMA version 10 * Sampling rates (in kHz) - 8, 11, 16, 22, 32, 44.1, 48 * Bit rates - All bit-rates in the range 5kbps to 384kbps

HT-C9930_ELS_0914.indd 11 2010-09-14 6:51:28

Notes on USB connection

Supported devices:

USB storage media, MP3 player, digital camera, USB card reader

1) Does not support if a folder or file name is longer than 125 characters.
2) A subtitle file bigger than 300 KB may not be properly displayed.
3) A certain USB/digital camera device may not be compatible with the product.
4) FAT16 and FAT32 file systems are supported.
   • NTFS file system is not supported.
5) Photo (JPEG), music (MP3) and video file should have their names in Korean or English. Otherwise, the file may not played.
6) Connect directly to the product's USB port. Connecting through another cable may raise problems with USB compatibility.
7) Inserting more than one memory device to a multi-card reader may not operate properly.
8) PTP protocol for digital camera is not supported.
9) Do not disconnect USB device during a "loading" process.
10) Bigger the image resolution, the longer the delay to displaying.
11) DRM applied MP3 files downloaded from a commercial site are not played back.
12) External HDD device is not supported.
13) Supported file formats

Format	Still Picture	Music
File name	JPG	MP3
File extension	JPG .JPEG	.MP3
Bit rate	–	80~384kbps
Version	–	–
Pixel	640x480	–
Sampling Frequency	–	44.1kHz

Accessories


Check for the supplied accessories below.



FM Antenna



User's Manual



Remote Control / Batteries (AAA size)



TX Card (for iPod/iPhone Wireless Transmitter)



Wireless LAN Adapter



System Cable



(small)

(For Power cord/HDMI cable)

(For Speaker cable/System cable)

Toroidal Ferrite Core

HT-C9930_ELS_0914.indd 12 2010-09-14 6:51:29


Wireless Dock Cradle for iPod/iPhone : HT-WDC10




Wireless Transmitter



Charging Cradle



DC Power Cord



DC Power Adaptor

Table Stand Set




Table Stand



Small Black screws (4x12: 4EA)

Wall Mount Set



Bracket Wall Mount




Bracket Set Mount



Small Black screws (4x12: 4EA)


Tallboy Type Stand Set




Stand Base



Pole Holder



Stand Pole



Deco-stand Rear




Siver screws (4x6:2EA+spare 1EA)/
Large Black screws (4x16:3EA+spare 1EA)

HT-C9930_ELS_0914.indd 13 2010-09-14 6:51:30

Getting Started

Description

Front Panel




1	POWER BUTTON (⏻)	Turns the product on and off.
2	DISPLAY	Displays the playing status, time, etc.
3	FUNCTION BUTTON	The mode switches as follows : **BD/DVD ➞ D. IN ➞ AUX ➞ iPod ➞ HDMI1 ➞ HDMI2 ➞ TUNER**
4	REMOTE CONTROL SENSOR	Detects signals from the remote control.
5	PLAY/PAUSE BUTTON	Plays a disc or pauses playback.
6	STOP BUTTON	Stops disc playback.
7	EJECT BUTTON	Ejects a Disc.
8	VOLUME CONTROL	Volume adjustment.
9	DISC TRAY	Insert disc here.

! CAUTION

- Heat on the top of the HT-C9930 main unit
  - The top side of the product may get warm after a long period of use.
    This is normal and does not indicate any defect or operation failure of the product.
    However, children should be prevented from touching the upper part of the product.

HT-C9930_ELS_0914.indd 14 2010-09-14 6:51:37

Rear Panel




1	SYSTEM CABLE JACK	Use the system cable to connect to the subwoofer. To activate the product, the subwoofer should be connected beforehand.
2	USB PORT	A USB storage device can be connected here and used as storage when connected to BD-LIVE. It can also be used for software upgrades and MP3/JPEG/DivX/MKV/MP4 playback.
3	WIRELESS LAN ADAPTER JACK	Can be used for network based services (see pages 62~67), BD-LIVE and software upgrade with a wireless LAN adapter.
4	USB OPEN BUTTON	Opens the USB Port.

NOTE

- Software upgrades using the USB Port must be performed with a USB memory flash stick only.

HT-C9930_ELS_0914.indd 15 2010-09-14 6:51:39

Rear Panel of the Subwoofer




1	COOLING FAN	The cooling fan supplies cool air to the subwoofer to prevent overheating and always revolves when the power is on.
2	TX CARD CONNECTION (WIRELESS)	The TX card enables communication between the product and the iPod/ iPhone Wireless Transmitter (HT-WDC10).
3	USB PORT (ONLY USE FOR AMP UPDATE)	It can be used only for software upgrades. (**ONLY USE FOR AMP UPDATE**) - No access to this port is allowed except for the service personnel (expert).
4	SYSTEM CABLE JACK	Use the system cable to connect to the product.
5	HDMI OUT JACK	Use an HDMI cable, connect this HDMI output terminal to the HDMI input terminal on your TV for the best quality picture.
6	HDMI IN JACKS	Receives digital video and audio signals simultaneously using an HDMI cable.
7	FM ANT JACK	Connect the FM antenna.
8	AUX IN JACKS	Connect to the 2CH analogue output of an external device. (such as a VCR)
9	OPTICAL JACK	Use this to connect external equipment capable of digital output.
10	LAN TERMINAL	Can be used for network based services (see pages 62~67), BD-LIVE and software upgrade under the network connection.
11	SPEAKER OUTPUT CONNECTORS	Connect the front, centre, subwoofer speakers.

! CAUTION

- Ensure a minimum of 10 cm of clear space on all sides of the cooling fan when installing the product.
- Do not obstruct the cooling fan or ventilation holes.

HT-C9930_ELS_0914.indd 16 2010-09-14 6:51:40


Tour of the Remote Control



HT-C9930_ELS_0914.indd 17 2010-09-14 6:51:42

Installing batteries in the Remote Control

* Battery size: AAA



NOTE

- Make sure to match the "+" and "–" ends of the batteries with the diagram inside the compartment.
- Assuming typical TV usage, the batteries last for about one year.
- The remote control can be used up to approximately 7 meters in a straight line.

Setting the Remote Control

You can control certain functions of your TV with this remote control.

When operating a TV with the remote control

1. Press the **BD RECEIVER/TV** button to set the remote control to TV mode.
2. Press the **POWER** button to turn on the TV.
3. While holding down the **POWER** button, enter the code corresponding to your brand of TV.
   - If there is more than one code listed for your TV in the table, enter one at a time to determine which code works.
   - **Example : For a Samsung TV**
     While holding down the **POWER** button, use the number buttons to enter 00, 15, 16, 17 and 40.
4. If the TV turns off, the setting is complete.
   - You can use the TV POWER, VOLUME, CHANNEL, and Numeric buttons (0~9).

NOTE

- The remote control may not work on some brands of TV's. Also, some operations may not be possible, depending on your brand of TV.
- The remote control will work with Samsung TVs by default.

TV Brand Code List

Brand	Code
Admiral (M.Wards)	56, 57, 58
A Mark	01, 15
Anam	01, 02, 03, 04, 05, 06, 07, 08, 09, 10, 11, 12, 13, 14
AOC	01, 18, 40, 48
Bell & Howell (M.Wards)	57, 58, 81
Brocsonic	59, 60
Candle	18
Cetronic	03
Citizen	03, 18, 25
Cinema	97
Classic	03
Concerto	18
Contec	46
Coronado	15
Craig	03, 05, 61, 82, 83, 84
Croslex	62
Crown	03
Curtis Mates	59, 61, 63
CXC	03
Daewoo	02, 03, 04, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 32, 34, 35, 36, 48, 59, 90
Daytron	40
Dynasty	03
Emerson	03, 15, 40, 46, 59, 61, 64, 82, 83, 84, 85
Fisher	19, 65
Funai	03
Futuretech	03
General Electric (GE)	06, 40, 56, 59, 66, 67, 68
Hall Mark	40
Hitachi	15, 18, 50, 59, 69
Inkel	45
JC Penny	56, 59, 67, 86
JVC	70
KTV	59, 61, 87, 88
KEC	03, 15, 40
KMC	15
LG (Goldstar)	01, 15, 16, 17, 37, 38, 39, 40, 41, 42, 43, 44
Luxman	18
LXI (Sears)	19, 54, 56, 59, 60, 62, 63, 65, 71
Magnavox	15, 17, 18, 48, 54, 59, 60, 62, 72, 89
Marantz	40, 54
Matsui	54
MGA	18, 40

Brand	Code
Mitsubishi/ MGA	18, 40, 59, 60, 75
MTC	18
NEC	18, 19, 20, 40, 59, 60
Nikei	03
Onking	03
Onwa	03
Panasonic	06, 07, 08, 09, 54, 66, 67, 73, 74
Penney	18
Philco	03, 15, 17, 18, 48, 54, 59, 62, 69, 90
Philips	15, 17, 18, 40, 48, 54, 62, 72
Pioneer	63, 66, 80, 91
Portland	15, 18, 59
Proton	40
Quasar	06, 66, 67
Radio Shack	17, 48, 56, 60, 61, 75
RCA/ Proscan	18, 59, 67, 76, 77, 78, 92, 93, 94
Realistic	03, 19
Sampo	40
Samsung	00, 15, 16, 17, 40, 43, 46, 47, 48, 49, 59, 60, 98
Sanyo	19, 61, 65
Scott	03, 40, 60, 61
Sears	15, 18, 19
Sharp	15, 57, 64
Signature 2000 (M.Wards)	57, 58
Sony	50, 51, 52, 53, 55
Soundesign	03, 40
Spectricon	01
SSS	18
Sylvania	18, 40, 48, 54, 59, 60, 62
Symphonic	61, 95, 96
Tatung	06
Techwood	18
Teknika	03, 15, 18, 25
TMK	18, 40
Toshiba	19, 57, 63, 71
Vidtech	18
Videch	59, 60, 69
Wards	15, 17, 18, 40, 48, 54, 60, 64
Yamaha	18
York	40
Yupiteru	03
Zenith	58, 79
Zonda	01
Dongyang	03, 54


HT-C9930_ELS_0914.indd 18 2010-09-14 6:51:43

Installation


You can install the product in one of the following three ways:
Choose a desired one according to the installation area and your decoration plan.

Installing on the Table Stand

1. Fit the rear round side of the product into the stand holes and fix it with 4 small black screws(4x12).
   - Ensure that you insert it in the right direction.




2. This is when the product has been installed properly on the table stand.




Installing on a Tallboy Type of Stand

If you want to place the product vertically on the floor, use a Tallboy type of stand featuring the stand base and pole. Proceed with the installation considering the size, installation area and position of the Tallboy stand.

1. Insert the system cable through the stand base hole.
   - The small port should be revealed from the top of the stand base so that you connect the product to it.




2. Loosen the screw on one end of the bracket-cable in the bottom of stand base and turn the bracket-cable aside. Arrange the system cable through the bottom hole and turn the bracket cable back to the original. Then, tighten it with the screw.




HT-C9930_ELS_0914.indd 19 2010-09-14 6:51:44


3. Fit the stand pole into the cable hole of the stand base and fix it with 3 large black screws(4x16).




4. Cover the top of the stand base with the deco-stand rear.




5. Fit the stand pole bracket into the rear hole of the product and fix it with 2 siver screws(4x6).
- Arrange the cables through the cable hole of the stand pole lest that any of them should protrude.



6. Insert the pole holder into the stand pole top down as shown.



7. This is when the product has been installed properly on the Tallboy type of stand.




HT-C9930_ELS_0914.indd 20 2010-09-14 6:51:48


Installing the Product on the Wall

Use the wall mount bracket if you want to install the product on the wall.


1. Place the wall mount bracket in a desired area of the wall and use 4 screws (not supplied) to fix it on the wall.




2. Attach the back unit bracket (bracket set mount) with the product by fastening provided 4 small black screws(4x12).



3. Fully insert the back bracket's clasp into the wall mount bracket receptacle and fix it by fully sliding to the down.



4. This is when the product has been installed properly on the wall.



HT-C9930_ELS_0914.indd 21 2010-09-14 6:51:53


Connections

This section involves various methods of connecting the product to other external components.
Before moving or installing the product, be sure to turn off the power and disconnect the power cord.

Connecting the Speakers

Connecting the Subwoofer

To activate the product, you must connect the subwoofer to the product using the system cable. Most of external connections including power supply, speakers and TV are made through the subwoofer.




! CAUTION

- **Do not plug or unplug the system cable during the power cord is plugged. Otherwise, it can cause damage to the product.**

Attaching the Toroidal Ferrite Core to the Power Cord of the Subwoofer


If you attach a Toroidal ferrite core to the power cord of the Subwoofer, it will help to prevent RF interference from radio signals.

1. Pull the fixing tab of the Toroidal ferrite core to open it.
2. Make three loops in the power cable of the subwoofer.
3. Attach the Toroidal ferrite core to the Subwoofer power cord as the figure shows and press it until it clicks.




Attaching the Toroidal Ferrite Core to the System Cable

1. Pull the fixing tab of the Toroidal ferrite core to open it.
2. Insert two cores into one end of the system cable, and the other core into the other end of the system cable (connected between product and subwoofer). Then, press to close the cores until you hear a click as shown.
   - Unlike attaching ferrite core to the power cable, do not make loops around the core with the system cable and simply plug in the core and fix it.



HT-C9930_ELS_0914.indd 22 2010-09-14 6:51:58



Position of the product

Place it on a stand or cabinet shelf, or under the TV stand.

Selecting the Listening Position

The listening position should be located about 2.5 to 3 times the distance of the TV's screen size away from the TV.
Example : For 32" TV's 2~2.4m
For 55" TV's 3.5~4m

Front Speakers L R	Place these speakers in front of your listening position, facing inwards (about 45°) toward you. Place the speakers so that their tweeters will be at the same height as your ear. Align the front face of the front speakers with the front face of the center speaker or place them slightly in front of the center speakers.
Centre Speaker C	It is best to install it at the same height as the front speakers. You can also install it directly over or under the TV.
Subwoofer SW	The position of the subwoofer is not so critical. Place it anywhere you like.

! CAUTION

- Do not let children play with or near the speakers. They could get hurt if a speaker falls.
- When connecting the speaker wires to the speakers, make sure that the polarity (+/–) is correct.
- Keep the subwoofer speaker out of reach of children so as to prevent children from inserting their hands or alien substances into the duct (hole) of the subwoofer speaker.
- Do not hang the subwoofer on the wall through the duct (hole).


✎ NOTE

- If you place a speaker near your TV set, screen colour may be distorted because of the magnetic field generated by the speaker. If this occurs, place the speaker away from your TV set.


HT-C9930_ELS_0914.indd 23 2010-09-14 6:52:02

Connections

Speaker Components



Assembled Speakers




NOTE

- Refer to page 25 to install the Speakers on the Tallboy Stand.

HT-C9930_ELS_0914.indd 24 2010-09-14 6:52:02

Installing the Speakers on the Tallboy Stand


1. Stretch out the speaker cable and get it through as shown.




✎ **NOTE**

- When installing the front speakers, match the label colour of the stand with the cable colour of the speaker.

2. Fit the stand pole into the stand base.
(if they do not fit with each other, the stand may get tilted from an improper installation.)



3. Tighten up the screws (large) (3.5x18, x3) as shown.



! CAUTION


- When you use a torque screwdriver, be careful not to put excessive force. Otherwise, it runs idle or can be damaged. (torque screwdriver- below 15 kg.f.cm)

HT-C9930_ELS_0914.indd 25 2010-09-14 6:52:08

Connections


Connecting Speaker Wire

1. Loosen the knob by turning counterclockwise.
2. Insert the bare part of the wire into the hole in the side of each terminal.
3. Tighten the knob by turning clockwise to secure the wire.




NOTE

- Keep the subwoofer speaker out of reach of children to prevent them from inserting their hands or objects into the duct (hole).
- Never touch speaker terminals while the power is on. Doing so could result in electric shock.
- Make sure the polarities (+ and -) are correct.



Connecting The Speakers

1. Press down the terminal tab on the back of the speaker.
2. Insert the black wire into black terminal(-) and the wire with band into the red(+) terminal, and then release the tab.
3. Connect the connecting plugs to the back of the Subwoofer by matching the colours of the speaker plugs to the speaker jacks.




HT-C9930_ELS_0914.indd 26 2010-09-14 6:52:10

Connecting External Devices/your TV via HDMI

HDMI is a standard digital interface for connection to such devices as a TV, projector, DVD player, Blu-ray player, set top box and more.

HDMI removes any loss of signal from analogue conversion, enabling you to enjoy video and audio sound quality as it was originally created in the digital source.



HDMI OUT : Connecting to a TV with an HDMI Cable

Connect an HDMI cable (not supplied) from the HDMI OUT jack on the back of the subwoofer to the HDMI IN jack on your TV.

NOTE

- Certain HDMI output resolutions may not work, depending on your TV.
- If an HDMI cable is connected or removed during playback of a CD-DA, MP3 or JPEG file, the product will stop playing.
- After making the video connection, set the Video input source on your TV to match the corresponding Video output (HDMI) on your product.
  See your TV owner's manual for more information on how to select the TV's Video Input source.
- If you have set the product's remote control to operate your TV, press the **TV SOURCE** button on the remote control and select HDMI as the external source of the TV.
- You must have an HDMI connection to enjoy videos with 3D technology.
- A long HDMI cable may cause a screen noise. If this is the case, set Deep Color to Off in the menu.

HDMI IN : Connecting to an External Component with an HDMI Cable

1. Connect an HDMI cable (not supplied) from the **HDMI IN1** or **HDMI IN2** jack on the back of the product to the HDMI OUT jack on your digital devices.
2. Press the **FUNCTION** button to select **HDMI1** or **HDMI2** input.
   The mode switches as follows : **BD/DVD ➞ D. IN ➞ AUX ➞ iPod ➞ HDMI1 ➞ HDMI2 ➞ TUNER**

HT-C9930_ELS_0914.indd 27 2010-09-14 6:52:14

Connections

HDMI Auto Detection Function

For possible HDMI resolutions, see page 36.

- This function is not available if the HDMI cable does not support CEC.
- HDMI connection description
  - HDMI outputs only a pure digital signal to the TV.
  - If your TV does not support HDCP, random noise appears on the screen.
- What is the HDCP?
  HDCP (High-band width Digital Content Protection) is a system for protecting BD/DVD content outputted via HDMI from being copied. It provides a secure digital link between a video source (PC, DVD. etc) and a display device (TV, projector. etc). Content is encrypted at the source device to prevent unauthorized copies from being made.

! CAUTION


- The Anynet+ function is supported only when an HDMI Cable is connected to the HDMI OUT of the product.

Connecting the FM Antenna

1. Connect the FM antenna supplied to the FM ANT Jack.
2. Slowly move the antenna wire around until you find a location where reception is good, then fasten it to a wall or other rigid surface.


NOTE

- This product does not receive AM broadcasts.



Attaching the Toroidal Ferrite Core to the Speaker Cable

1. Open the smaller ferrite core by pulling up the tab.
2. Arrange up the speaker cables that are connected to the FRONT L (+,-) terminal before making 3 loops of them.
3. Attach the ferrite core to the arranged cables and press to close it until you hear a click.
   - Insert the ferrite core as close to the sub woofer as possible.
4. Follow steps 1 through 3 above and insert the ferrite core to the speaker cables that are connected to the FRONT R (+,-) terminal of the sub woofer.




! CAUTION

- Before connecting the speakers, connect the main unit to the subwoofer using the system cable. See page 22.

HT-C9930_ELS_0914.indd 28 2010-09-14 6:52:16

Connecting Audio from External Components



OPTICAL : Connecting an External Digital Component

Digital signal components such as a Cable Box/Satellite receiver (Set-Top Box).

1. Connect the Digital Input (OPTICAL) on the product to the Digital Output of the external digital component.
2. Press the **FUNCTION** button to select **D.IN** input.
   - The mode switches as follows : **BD/DVD → D. IN → AUX → iPod → HDMI1 → HDMI2 → TUNER**

NOTE

- To see video from your Cable Box/Satellite receiver, you must connect it's video output to a TV.
- This system supports Digital sampling frequencies of 32 kHz of higher from external digital components.
- This system supports only DTS and Dolby Digital audio, MPEG audio which is bitstream cannot be supported.

AUX : Connecting an External Analogue Component

Analogue signal components such as a VCR.

1. Connect AUX IN (Audio) on the product to the Audio Out of the external analogue component.
   - Be sure to match connector colours.
2. Press the **FUNCTION** button to select **AUX** input.
   - The mode switches as follows : **BD/DVD → D. IN → AUX → iPod → HDMI1 → HDMI2 → TUNER**

NOTE

- You can connect the Video Output jack of your VCR to the TV, and connect the Audio Output jacks of the VCR to this product.

HT-C9930_ELS_0914.indd 29 2010-09-14 6:52:19

Connections


Connecting to the Network

This product supports network based services (see pages 62~67), BD-LIVE and software upgrade under the network connection. It is recommended to use an AP (Access Point) or IP router.

For more information on router connection, refer to the user manual of the router or contact the router manufacturer for technical assistance.

Cable Network

1. Using the Direct LAN Cable (UTP cable), connect the LAN terminal of the product to the LAN terminal of your modem.
2. Set the network options. (See page 43)



NOTE


- Internet access to Samsung's software update server may not be allowed, depending on the router you use or the ISP's policy. For more information, contact your ISP (Internet Service Provider).
- For DSL users, please use a router to make a network connection.
- For the AllShare function, a PC must be connected in the network as shown in the figure.

HT-C9930_ELS_0914.indd 30 2010-09-14 6:52:21

Wireless Network

You can connect to the network with a Wireless IP sharer.

1. A wireless AP/IP router is required to make a wireless network connection. Connect the wireless LAN adapter to the Wireless LAN Adapter on the rear panel of the product.
   - This unit is compatible with the supplied Wireless LAN Adapter.
2. Set the network options. (See page 43)




NOTE

- You must use a wireless IP sharer that supports IEEE 802.11 a/b/g/n. (n is recommended for stable operation of the wireless network.)
- Wireless LAN, in its nature, may cause interference, depending on the use condition (AP performance, distance, obstacle, interference by other radio devices, etc).
- Set the wireless IP sharer to Infrastructure mode. Ad-hoc mode is not supported.
- When applying the security key for the AP (wireless IP sharer), only the following is supported.
  1) Authentication Mode : WEP, WPAPSK, WPA2PSK
  2) Encryption Type : WEP, AES
- For the AllShare function, a PC must be connected in the network as shown in the figure.


HT-C9930_ELS_0914.indd 31 2010-09-14 6:52:25

Before Starting (Initial Settings)


1. Turn on your TV after connecting the product. (When the product is connected to TV for the first time, product will turn on automatically and the Initial Settings screen will be displayed.)



2. Press the ▲▼ buttons to select the desired language, then press the **ENTER** button.
3. Press the **ENTER** button to select Start button.



4. Press the ▲▼ buttons to select desired TV Aspect ratio, then press the **ENTER** button. (See page 35)
5. Press the ◄► buttons to the select the desired Network Settings: Wired, Wireless or PBC(WPS), then press the **ENTER** button. (See pages 43~46)
   The Network Test will start and Initial Settings will be completed.



6. Press the **OK** button.
   The home menu will be displayed. (For more information about home menu, please see page 33)

• Home Menu




NOTE

- When the product is connected to TV for the first time, product will turn on automatically. Do not confuse because this is not malfunction.
- The home menu will not be displayed if you do not configure the initial settings.
- If you press the **BLUE(D)** button during the Musical Auto Calibration/Network setup, you can access the home menu even if the network setup is not completed yet.
- When you return to home menu, the full screen mode will be cancelled automatically.

HT-C9930_ELS_0914.indd 32 2010-09-14 6:52:26

- If you want to display Initial Settings screen again in order to make changes, press the **STOP** (■) button on the front panel of the product for more than 5 seconds with no disc inserted.
- Use the HDMI cable to connect the product to an **Anynet+ (HDMI-CEC)**-compliant Samsung TV. If the TV uses a language supported by the product, that language will be set to a preferred language automatically. However, the **Anynet+ (HDMI-CEC)** feature should be set to **On** in both TV and the product.
- If the product is left in the stop mode for more than 5 minutes without being operated, a screen saver will appear on your TV. If the product is left in the screen saver mode for more than 25 minutes, the power will automatically turn off except during playback of a CD-DA (Automatic Power-Off Function).


Setting the Menu



1	**MENU** Button : Press this to move to the home menu.
2	**RETURN** Button : Return to the previous menu.
3	**ENTER / DIRECTION** Button: Press the arrow buttons to move the cursor and select an item. Press the **ENTER** button to launch the selected item or confirm the setting.
4	**EXIT** Button : Press this to exit the menu.

1. Press the **POWER** button. The Home Menu will appear.

• **Home Menu**



1	Selects the Internet@TV.
2	Selects the Videos.
3	Selects the Music.
4	Selects the Photos.
5	Selects the Settings.
6	Displays buttons available.

2. Press the ◄► buttons to select **Settings**, then press the **ENTER** button.
3. Press the ▲▼ buttons to select the desired submenu, then press the **ENTER** button.
4. Press the ▲▼ buttons to select the desired item, then press the **ENTER** button.
5. Press the **EXIT** button to exit the menu.

NOTE

- When the product is connected to the network, select Internet@TV from the home menu. Download desired content from **Samsung AppS**.
- The access step may differ depending on the selected menu.
- The OSD (On Screen Display) may change in this product after upgrading the software version.


HT-C9930_ELS_0914.indd 33 2010-09-14 6:52:34

Display

You can configure various display options such as the TV Aspect, Resolution, 3D, etc.

3D

Select whether to play a Blu-ray Disc with 3D contents in 3D Mode.



3D Mode

- **Auto** : The 3D Blu-ray Disc is played in 3D mode if your product detects a TV which supports it. It is played in 2D mode if your product detects a TV which cannot support it.
- **3D** : The 3D Blu-ray Disc is played in 3D mode at all times. If a TV cannot support 3D Blu-ray discs, the TV's screen can be black.
- **2D** : The 3D Blu-ray Disc is played in 2D mode at all times. Choose this to view a picture without 3D effect or when a TV cannot support 3D Blu-ray discs.

NOTE

- If you press the **STOP**(■) button once during the 3D disc playback, 3D mode option will be deactivated.
  To activate 3D mode option during the 3D disc playback, press the **STOP**(■) button twice.
- Depending on the content and its play position, vertical black bars could be seen on left or right or both sides.

TV Screen Size

Lets you enter the actual screen size of your TV so that the product can adjust the image according to the screen size and display an optimal 3D image. (The maximum allowed screen size is 116 inches for this product.)

! CAUTION

- If you want to enjoy a 3D content, connect a 3D device (3D compliant AV receiver or TV) to the product and wear a 3D glass before playing the 3D content.
- All 3D signals are output only using the HDMI cable and through the HDMI OUT port.
- As the video resolution in 3D play mode is fixed according to the resolution of the original 3D video, you can not change the resolution to your preference.
- Some functions such as BD Wise, or setting the screen size or resolution may not operate properly in 3D play mode.
- You must use a high-speed HDMI cable for a proper output of the 3D signal.
- Stay at least three times of the length of the screen distant from the TV.
  - It is recommended to place the 3D video screen forward at eye level.
- If the product is connected to some 3D devices, the 3D effect may not function properly.
- You can not use this product for switching a 2D content to 3D.

HT-C9930_ELS_0914.indd 34 2010-09-14 6:52:37

TV Aspect

Depending on the type of television you have, you may want to adjust the screen setting.

• 16:9 Normal	
	Certain movies(4:3 source) will be displayed in 4:3 Pillarbox (black bars on sides of picture) if 16:9 normal is selected.
• 16:9 Wide	
	You can view the full 16:9 picture on your widescreen TV.
• 4:3 Letter Box	
	Select when you want to see the total 16:9 ratio screen a Blu-ray Disc/DVD supplies, even though you have a TV with a 4:3 ratio screen. Black bars will appear at the top and bottom of the screen.
• 4:3 Pan-Scan	
	Select when you want to see the 16:9 video supplied by the Blu-ray Disc/DVD without the black bars on top and bottom, even though you have a TV with a 4:3 ratio screen(extreme left and right portion of the movie picture will be cut off).

NOTE

- Depending on the disc type, some aspect ratios may not be available.
- If you select an aspect ratio and option which is different than the aspect ratio of your TV screen, then the picture might appear to be distorted.
- If you select the 4:3 Pan-Scan or 4:3 Letter Box, you can't see full screen by pressing the **FULL SCREEN** button on the remote control.

BD Wise (Samsung Products only)

BD Wise is Samsung's latest inter-connectivity feature.

When you connect Samsung products with BD-Wise to each other via HDMI, the optimum resolution will be set automatically.

- **Off** : The output resolution will be fixed according to the Resolution previously set, regardless of the resolution of the disc.
- **On** : The original resolution of the BD/DVD disc will be output to the TV.

NOTE

- If you want to change the resolution in BD Wise, you must set BD Wise to **Off** in advance.
- If you set off the BD Wise, the resolution of the connected TV will be adjusted to its maximum resolution automatically.
- If the product is connected to a device that does not support BD Wise, you can not use BD Wise function.
- For a proper operation of BD Wise, set the BD Wise menu of both the product and the TV to **On**.

Resolution

Sets the output resolution of the HDMI video signal.
The number in 1080p, 1080i, 720p, 576p(480p) indicates the number of lines of video.
The i and p indicate interlace and progressive scan, respectively.

- **Auto** : It automatically checks and sets the optimal resolution.
- **BD Wise** : Automatically sets the optimal resolution when connected via HDMI to a TV with the BD Wise feature. (The BD Wise menu item appears only if BD Wise is set to On.)
- **1080p** : Outputs 1080 lines of progressive video.
- **1080i** : Outputs 1080 lines of interlaced video.
- **720p** : Outputs 720 lines of progressive video.
- **576p/480p** : Outputs 576(480) lines of progressive video.

HT-C9930_ELS_0914.indd 35 2010-09-14 6:52:39

Resolution according to the output mode

• Blu-ray Disc playback

Setup \ Output	HDMI
Auto	Optimal Resolution
1080p, Movie Frame(24Fs) off	1080p@60F
1080p/1080i, Movie Frame(24Fs) on	1080p@24F
1080i, Movie Frame(24Fs) off	1080i
720p	720p
576p(480p)	576p(480p)

• DVD playback

Setup \ Output	HDMI
Auto	Optimal Resolution
1080p	1080p@60F
1080i	1080i
720p	720p
576p(480p)	576p(480p)

NOTE

- If the connected TV does not support Movie Frame or the selected resolution, the message "If no pictures are shown after the selection, please wait for 15 seconds. And then, the resolution will be reverted to the previous value automatically. Would you like to make a selection?" will be displayed.
  If you select **Yes** and the resolution is not supported, the TV's screen will be blank. Please wait for 15 seconds and the resolution will be reverted to the previous value automatically.
- If the screen is blank, press and hold the **STOP** (■) button on the front of the product for more than 5 seconds (no disc inserted). All settings are restored to the factory default. Follow the steps on the previous page to access each mode and select the Display Setup that your TV will support.
- When the factory default settings are restored, all the user data stored in the BD data will be deleted.
- The Blu-ray Disc must have the 24 frame feature in order to use the Movie Frame (24Fs) mode.
- If the HDMI Auto Detection feature does not work, you can't select the 1080p resolution or Movie Frame (24Fs).

HT-C9930_ELS_0914.indd 36 2010-09-14 6:52:52

HDMI Format

You can optimize the colour setting from the HDMI output. Select a connected device Type.

- **TV** : Select if connected to a TV via HDMI.
- **Monitor** : Select if connected to a Monitor via HDMI.

✎ NOTE

- A TV or monitor has to be connected to the product before you select this option.

Movie Frame (24Fs)

Setting the Movie Frame (24Fs) feature to On allows you to adjust the product's HDMI output to 24 frames per second for improved picture quality. You can enjoy the Movie Frame (24Fs) feature only on a TV supporting this frame rate. This menu can only be selected in 1080i or 1080p HDMI output resolution modes.

- **Off** : Movie Frame (24Fs) functions will not work.
- **On** : Movie Frame (24Fs) functions will work.

✎ NOTE

- Two types of frame rates may be included, depending on the disc: Movie material (24 frame) and Video material (30 frame). When the setting switches between Movie (24 frame) and Video (30 frame), the screen may blink for a few seconds.
- If your TV does not support Movie Frame (24Fs) function, the pop-up message will be displayed.

Progressive Mode

Set to improve picture quality when viewing DVDs.

- **Auto** : Select this to have the product automatically set the best picture for the DVD you're watching.
- **Video** : Select this for the best picture from Concert or TV show DVDs.

Still Mode

Set the type of picture shown when you pause DVD playback.

- **Auto**: Automatically set the best still picture depending on the content.
- **Frame** : Select when pausing a scene with a little action.
- **Field** : Select when pausing a scene with a lot of action.

HDMI Deep Color


Set to output the picture from the HDMI OUT jack with Deep Colour or not. Deep Colour allows more accurate colour reproduction with deeper colour depth.

- **Auto**: The picture will be output with Deep Colour to the connected TV which supports HDMI Deep Colour.
- **Off** : The picture will be output without Deep Colour.

HT-C9930_ELS_0914.indd 37 2010-09-14 6:52:52

Audio

Speaker Setting




Level

You can adjust the balance and level for each speaker.

Adjusting Front/Centre/Subwoofer Speaker Level


- The volume level can be adjusted in steps from +6dB to -6dB.
- The sound gets louder as you move closer to +6dB and quieter as you get closer to -6dB.



Distance

If the speakers cannot be placed at equal distances from the listening position, you can adjust the delay time of the audio signals from the front, centre and subwoofer speakers.

- You can set the Speaker Distance between 1ft(0.3m) and 30ft(9.0m).




Test Tone

Use the Test Tone feature to check the speaker connections.

Press the ◄, ► buttons to select **All**.

- A test tone will be sent to **Front L → Center → Front R → Subwoofer** in order so you can make sure the speakers are set up correctly.

To stop the test tone, press the ◄, ► buttons to select **Off**.



NOTE

- When HDMI Audio is ON (audio is produced through TV speakers), the Test Tone function is not available.

HT-C9930_ELS_0914.indd 38 2010-09-14 6:52:52

EQ Optimizer

Set optimal EQ automatically depending on the region.

- **Off** : Turn EQ Optimizer off.
- **On** : Turn EQ Optimizer on.

HDMI Audio

The audio signals transmitted over the HDMI Cable can be toggled On/Off.

- **Off :** Video is transmitted over the HDMI connection cable only, and audio is output through your product speakers only.
- **On :** Both video and audio signals are transmitted over the HDMI connection cable, and audio is output through your TV speakers only.

✎ **NOTE**

- HDMI Audio is automatically down-mixed to 2ch for TV speakers.

Digital Output

Set Digital output depending on the connected receiver. (For more details, please refer to the digital output selection)

- **PCM**
- **Bistream (Re-encode)**
- **Bistream (Audiophile)**

Blu-ray Discs may include three audio streams.

- Primary Audio : The audio soundtrack of the main feature.
- Secondary Audio : Additional soundtrack such as director or actor's commentary.
- Interactive Audio : Interactive sounds will be heard when selected. Interactive Audio is different on each Blu-ray Disc.

✎ **NOTE**

- Be sure to select the correct Digital Output or you will hear no sound or a loud noise.
- If the HDMI device (Receiver, TV) is not compatible with compressed formats (Dolby digital, DTS), the audio signal outputs as PCM.
- Secondary and Effect audio will not be heard with regular DVDs.
- Some Blu-ray Discs do not have Secondary and Effect audio.
- This Digital Output setup does not effect the analogue (L/R) audio or HDMI audio output to your TV.
  It effects the optical and HDMI audio output when connected to a receiver.
- If you play MPEG audio soundtracks, audio signal outputs PCM regardless of Digital Output Selections (PCM or Bitstream).

HT-C9930_ELS_0914.indd 39 2010-09-14 6:52:58

Digital Output Selection

Setup	Definition	Connection	Audio Stream						
			PCM	Dolby Digital	Dolby Digital Plus	Dolby TrueHD	DTS	DTS-HD HRA	DTS-HD MA
PCM	Decodes Primary, Secondary and Effect audio streams together into PCM audio.	HDMI Receiver	Up to PCM 7.1ch	Up to PCM 5.1ch	Up to PCM 7.1ch	Up to PCM 7.1ch	Up to PCM 6.1ch	Up to PCM 7.1ch	Up to PCM 7.1ch
Bitstream (Re-encode)	Decodes Primary, Secondary and Effect audio streams together into PCM audio, then re-encodes the PCM audio into DTS bitstream.	HDMI	DTS	DTS	DTS	DTS	DTS	DTS	DTS
Bitstream (Audiophile)	Outputs only the Primary audio soundtrack (main soundtrack of the movie) so that your receiver can decode the audio bitstream. You will not hear Secondary and Effect audio.	HDMI 1.3 Receiver	Up to PCM 7.1ch	Dolby Digital	Dolby Digital Plus	Dolby TrueHD	DTS	DTS-HD HRA	DTS-HD MA

Dynamic Range Control

You can listen at low volumes but still hear dialog clearly. This is only active when a Dolby Digital signal is detected.

- **Off** : Turn Dynamic Range Control off.
- **On** : Choose to listen to a movie at a lower volume without losing clarity of dialog.
- **Auto** : The Dynamic Range Control will be set automatically based on the information provided by the Dolby TrueHD Soundtrack.

AV Sync

Video may look slower than the audio when the product is connected to a digital TV. If this occurs, adjust the audio delay time to match the video.

- You can set the audio delay time between 0 msec and 300 msec. Set it to the optimal status.

Audio Return Channel

You can enjoy TV sound via Home Cinema speakers by using just one HDMI cable.

- **Off** : Turn Audio Return Channel funtion off.
- **Auto** : Listen to TV sound from Home Cinema speakers if your TV is compatible with Audio Return Channel function.

NOTE

- When Anynet+ (HDMI-CEC) is Off, the Audio Return Channel function is not available.
- Using an ARC (Audio Return Channel)-uncertified HDMI cable may cause a problem in compatibility.

HT-C9930_ELS_1012.indd 40 2010-10-12 3:08:07

System

Initial Settings

By using the Initial Settings, you can set language, TV aspect and Network setting, etc. For more information on the settings, refer to the corresponding section in this user manual.

Internet@TV Screen Size

Set the Internet@TV Screen to the optimal size.

- **Size 1** : Display smaller application icons, you may see some black on sides of screen.
- **Size 2** : Display normal application icons.
- **Size 3** : Display larger application icons, image may be too large for your TV screen.

Anynet+ (HDMI-CEC)

Anynet+ is a convenient function that offers linked operations with other Samsung products with the Anynet+ feature.

To operate this function, connect this product to a Samsung TV with an HDMI cable.
You can operate this product using a Samsung TV remote control and start disc playback simply by pressing the **PLAY** (►) button on the TV's remote control.
For more information, please see the TV user manual.


- **Off** : Anynet+ function will not work.
- **On** : Anynet+ function will work.

NOTE

- This function is not available if the HDMI cable does not support CEC.
- If your Samsung TV has an Anynet+ logo, then it supports the Anynet+ function.
- Depending on your TV, certain HDMI output resolutions may not work.
  Please refer to the user manual of your TV.
- The Anynet+ function is supported only when an HDMI Cable is connected to the HDMI OUT of the product.
- If the HDMI cable or the power cord is unplugged, or if the product is turned off abnormally due to power failure, first connect the HDMI cable again; turn on all devices including the product, and use the ANYNET+ function under the TV menu to activate all connected devices again.

BD Data Management

Enables you to manage the downloaded contents from a Blu-ray Disc that supports the BD-LIVE service.
You can check the device information including the storage size, delete the BD data or change the Flash memory device. Change Device allows you to select either the product's Internal Memory or External Memory (connected USB Device). If the data to be stored from BD-LIVE is greater than the size of the remaining memory or the Internal Memory is full, connect an External USB device, then select External Device in the menu.



HT-C9930_ELS_0914.indd 41 2010-09-14 6:52:58

Description of Device(Storage) Information on the Product


- **Total Size :** Total size of the Device (Storage).
- **Available Size :** Available size of the Device (Storage).

NOTE

- In the external memory mode, disc playback will be stopped if you disconnect the USB device in the middle of the playback.
- Only those USB devices formatted in FAT file system (DOS 8.3 volume label) are supported, and it is recommended to use USB devices that support USB 2.0 protocol, 4 MB/sec or faster read/write speed.
- The Resume Play function may not work after formatting the storage device.
- The total size of BD Data Management may differ, depending on the software version.

Clock


Set time-related functions.



- **Clock Mode** : You can select **Auto** or **Manual**. If you select **Manual**, the **Clock Set** menu will be activated while **DST** will be deactivated.
- **Clock Set** : You can specify the current time and date manually.
- **Time Zone** : You can specify the time zone that is applicable to your area.
- **DST** : You can set DST (Daylight Saving Time) 1 hour, 2 hours and off.

DivX(R) Registration

View DivX(R) VOD Registration Code to purchase and play DivX(R) VOD content.




NOTE

- This option is not activated if you select OK. To activate this option, please activate the DivX(R) Deactivation.

DivX(R) Deactivation

Select this to get a new registration code.



NOTE

- This function can be operated when DivX(R) Registration function is deactivated.

HT-C9930_ELS_0914.indd 42 2010-09-14 6:53:00

Network

To begin setting up the network connection for your product, follow these steps:

1. In the Home menu, press the ◄► buttons to select the **Settings**, and then press the **ENTER** button.
2. Press the ▲▼ buttons to select **Network**, and then press the **ENTER** button.
3. Press the ▲▼ buttons to select **Network Settings**, and then press the **ENTER** button.
4. Press the ▲▼ buttons to select **Network Type**, and then press the **ENTER** button.
5. Press the ▲▼ buttons to select **Wired** or **Wireless**, and then press the **ENTER** button.
6. Go to the next section.

Network Settings

Please contact your ISP to find out if your IP address is static or dynamic. If it is dynamic, we recommend using the Auto setting. This is the easiest and will work in the majority of cases. If it is static, you must use the manual set up procedure.

Directions for wired networks are below. Directions for wireless networks are after the directions for wired networks.

Wired Network


1. In the Network Settings menu, press the ▲▼ buttons to select **Network Setting**, and then press the **ENTER** button.
   The Internet Protocol Setup screen appears.
2. Press the ► button, then select **Auto** or **Manual**, and then press the **ENTER** button.

Setting Up a Wired Connection - Auto

1. If you selected **Auto**, the Network Function acquires and fills in the values for IP Address, Subnet Mask, etc., automatically.

✎ **NOTE**

- This process can take up to five minutes.



2. After the Network Function has acquired the network values, press the **RETURN** button. Then, run a Network Test to ensure the product has connected to your network (See page 46).
3. If the Network Function does not acquire the network values or you selected Manual, go to the directions for Manual Setup.

Setting Up a Wired connection - Manual


If the Auto Setting does not work, you'll need to set the Network Setting values manually.

To get the Network setting values from most Windows computers, follow these steps:

1. Right click the Network icon on the bottom right of the screen.
2. In the pop-up menu, click Status.
3. On the dialog that appears, click the Support tab.
4. On the Support tab, click the Details button. The Network settings are displayed.

To enter the Network settings into your product, follow these steps:

1. On the Internet Protocol Setup screen, press the **ENTER** button.
2. Press the ▲▼ buttons to select **Manual**, and then press the **ENTER** button.
3. Press the ▼ button to go to the first entry field (IP Address).



HT-C9930_ELS_0914.indd 43 2010-09-14 6:53:05

4. Use the number buttons on your remote to enter numbers.
5. When done with each field, use the ► button to move successively to the next field.
   You can also use the other arrow buttons to move up, down, and back.
6. Enter the **IP Address**, **Subnet Mask**, and **Gateway** values.
7. Press the ▼ button to go to **DNS**.
8. Press the ▼ button to go to the first DNS entry field.
9. Press the **RETURN** button on your remote.
10. Run a Network Test to ensure the product has connected to your network (See page 46).

Wireless Network

You can setup the wireless network three ways:

- Using PBC(WPS)
- Using the Auto Network Search function.
- Manually.

Each method is described below.

Setting Up the Wireless Network Connection - PBC(WPS)

The easiest way to set up the wireless network connection is using the PBC(WPS) function.
If your wireless router has a PBC(WPS) button, follow these steps:

1. In the Network Settings menu, press the ▲▼ buttons to select **Network Setting**, and then press the **ENTER** button.
   The Internet Protocol Setup screen appears.
2. Press the **RED(A)** button on the remote control.
3. Press the **PBC(WPS)** button on your router within two minutes. Your product displays the Network Selection Screen, and automatically acquires all the network setting values it needs and connects to your network. When it is done, it displays an **OK** button. Press the **ENTER** button on your remote.
4. After the network connection is set up, press the **RETURN** button to exit the Network Setting screen.


Setting Up the Wireless Network Connection - Auto Network Search

Most wireless networks have an optional security system that requires devices that access the network to transmit an encrypted security code called an Access or Security Key. The Security Key is based on a Pass Phrase, typically a word or a series of letters and numbers of a specified length you were asked to enter when you set up security for your wireless network. If you use this method of setting up the network connection, and have a Security Key for your wireless network, you will have to enter the Pass Phrase during the setup process.

▪ Setting Up the Network Connection

To set up the wireless connection using Auto Network Search, follow these steps:

1. In the Network Settings menu, press the ▲▼ buttons to select **Network Setting**, and then press the **ENTER** button.
   The Internet Protocol Setup screen appears.
2. Press the ▲▼ buttons to select the **Internet Protocol Setup**, and then press the **ENTER** button.
3. Press the ▲▼ buttons to select **Auto** or **Manual**, and then press the **ENTER** button.
4. If you selected **Auto**, press the ▲ button to go to **Select a network**, and then press the **ENTER** button.
   The Network function searches for available wireless networks.
   When done, it displays a list of the available networks.




HT-C9930_ELS_0914.indd 44 2010-09-14 6:53:07

5. In the list of networks, press the ▲▼ buttons to select a network, and then press the **ENTER** button.
6. If the PIN/Security pop-up appears, go to Step 7. If the Network Connecting Screen appears, go to Step 11.
7. Press the ▲▼ buttons to select PIN or Security.
   For most home networks, you would select Security (for Security Key).
8. On the Security screen, enter your network's Pass Phrase.

✎ **NOTE**

- You should be able to find the Pass Phrase on one of the set up screens you used to set up your router or modem.



9. To enter the Pass Phrase, follow these general directions:
   - Press the number keys on your remote to enter numbers.
   - Use the arrow keys on your remote to move from button to button on the Security Key screen.
   - Pressing the **RED (A)** button on the remote lets you change the text displayed on the buttons to lower case, upper case, numbers, or icons. To enter a letter or symbol, move the cursor to the letter or symbol, and then press the **ENTER** button.
   - To delete the last letter or number you entered, press the **GREEN (B)** button.
10. When done, press the **BLUE (D)** button on your remote, and then press the **ENTER** button.
11. Wait until the connection confirmation message is displayed, and then press the **ENTER** button. The Network Settings screen reappears.
12. To test the connection, press the ▼ button to select **Network Test**, and then press the **ENTER** button.


Setting Up the Wireless Network Connection - Manual

If the Auto Setting does not work, you need to enter the Network settng values manually.
To get the Network setting values from most Windows computers, follow these steps:

1. Right click the Network icon on the bottom right of the screen.
2. In the pop-up menu, click Status.
3. On the dialog that appears, click the Support tab.
4. On the Support tab, click the Details button. The Network settings are displayed.

To Enter the Network settings into your product, follow these steps:

1. On the Internet Protocol Setup screen, press the **ENTER** button.
2. Press the ▲▼ buttons to select **Manual**, and then press the **ENTER** button.
3. Press the ▼ button to go to the first entry field (IP Address).



4. Use the number buttons to enter numbers.

HT-C9930_ELS_0914.indd 45 2010-09-14 6:53:07

5. When done with each field, use the ► button to move successively to the next field.
   You can also use the other arrow buttons to move up, down, and back.
6. Enter the **IP Address**, **Subnet Mask**, and **Gateway** values.
7. Press the ▼ to go to **DNS**.
8. Press the ▼ button to go to the first DNS entry field. Enter the numbers as above.
9. When done, press the ▲ button to return to Access Point Selection. Select the network, and then press the **ENTER** button.
10. Go to Step 6 in the Automatic Wireless procedure above, and follow the directions from that point on.

Network Test

Use this menu to connect the wired network or check whether your network connection is working or not.

Network Status

Check whether a connection to the network and the Internet have been established.

BD-Live Internet Connection

Set whether to allow internet connection when BD-LIVE service is used.

- **Allow(All)** : The Internet connection will be allowed for all BD-LIVE contents.
- **Allow(Valid Only)** : The Internet connection will be allowed only for BD-LIVE contents containing a valid certificate.
- **Prohibit** : No Internet connection will be allowed for any BD-LIVE content.

NOTE

- **What is a valid certificate?**
  When the product uses BD-LIVE to send the disc data and request to the server to certify the disc, the server uses the transferred data to check if the disc is valid and sends the certificate back to the product.
- The Internet connection may be restricted while you are using BD-LIVE contents.

Language

You can select the language you prefer for home menu, disc menu, etc.

- **On-Screen Menu** : Select the language for the on-screen displays.
- **Disc Menu** : Select the language for the disc menu displays.
- **Audio** : Select the language for disc audio.
- **Subtitle** : Select the language for disc subtitles.

NOTE

- The selected language will only appear if it is supported on the disc.


HT-C9930_ELS_0914.indd 46 2010-09-14 6:53:09

Security

When you operate this menu for the first time, password setup screen will be displayed. Enter the desired 4-digit password using the number buttons. (Default password is set to 0000.)


Parental Rating

This function works in conjunction with Blu-ray Disc/DVDs that have been assigned a rating, which helps you control the types of Blu-ray Disc/DVDs that your family watches.
Select the rating level you want to set. A larger number indicates that the program is intended for adult use only. For example, if you select up to Level 6, discs that contain Level 7, 8 will not play.



Change Password

Change the 4-digit password used to access security functions.



If you forgot your password

1. Remove the disc.
2. Press and hold the **STOP** (■) button on the front panel for 5 seconds or more.
   All settings will revert to the factory settings.


NOTE

- When the factory default settings are restored, all the user data stored in the BD data will be deleted.

General

Background

Change the background theme of the menu screen.



Front Display

Change the brightness of the front panel.

- **Auto** : Dim during playback only.
- **Dim** : Dim the display window.
- **Bright** : Brighten the display window.

Power On/Off Sound

Play a melody when the product is turned on and off.


- **Off** : Turn Power Sound Off.
- **On** : Turn Power Sound On.

HT-C9930_ELS_0914.indd 47 2010-09-14 6:53:10

Support

Software Upgrade

This menu allows you to upgrade software for performance improvements or additional services. You can check the current software version, upgrade by internet and set the Auto upgrade notification. If the product is properly connected to the network by cable or wirelessly, the product will automatically connect to our website each time it is turned on and download update files if any valid upgrade exists.




1. To select **By Internet**, press the **ENTER** button.
   A popup message will appear if an update is available.
2. If you select **Yes**, the product will turn off automatically before restarting.
   (Never turn it on manually.)
3. The update progress popup will appear. When the update is completed, the product will turn back off automatically.
4. Press the **POWER** button to turn on the product.

NOTE

- The Update will be completed when the product turns off after restarting. Press the **POWER** button to turn on the updated product for your use. Never turn off or on the product manually during the update process.
- Samsung Electronics shall take no legal responsibility for product malfunction caused an unstable internet connection or consumer negligence during software upgrade.

You can update software in any of the two ways as follows: Software update is the same as in the **By Internet** menu.

- **USB** : Visit www.samsung.com/bluraysupport, then download and store the latest software (RUF file) into the USB flash drive. Connect the USB flash drive to the USB port of the product (disc tray must be empty) to update the software, then follow the on-screen instructions.



- **CD** : Visit www.samsung.com/bluraysupport, download and write the latest software (RUF file) onto a disc. Insert and play the disc in the product to start the update, then follow the on-screen instructions.

NOTE

- Software upgrades using the USB PORT jack must be performed with no disc inside.
- If you want to cancel the upgrade in the process of downloading the upgrade data, press the **ENTER** button.
- When the system upgrade is done, check the software details in the software Upgrade menu.
- Do not turn off the product during the System Upgrade, as it may cause the product to not work properly.
- Do not use USB devices other than USB Flash Drives to do software upgrades when using the USB PORT jack.

Contact Samsung

Provide contact information for assistance with your product.

HT-C9930_ELS_0914.indd 48 2010-09-14 6:53:15

Playing a Disc

Playback

1. Insert a disc into the disc slot with the disc's label facing front.
2. Press the **PLAY** (►) button.

Playback related buttons

PLAY (►)	Starts playback.
STOP (■)	Stops playback. • If pressing the button once: The stop position will be memorized. • If pressing the button twice: The stop position will be not memorized. (With some Blu-ray discs (BD-J), this function may not work.)
PAUSE (II)	Pauses playback.

✎ **NOTE**

- "Not Available" will appear when an invalid button is pressed.

Disc Structure

The contents of disc are usually divided as below.

- **Blu-ray Disc, DVD-VIDEO**



- **Audio CD (CD-DA)**



- **MP3, WMA, DivX, MKV and MP4**



Using the Disc menu / Title menu / Popup menu

Using the Disc Menu

BD-ROM DVD-VIDEO

1. During playback, press the **DISC MENU** button on the remote control.
2. Press the ▲▼◄ ► buttons to make the desired selection, then press the **ENTER** button.




✎ **NOTE**

- Depending on the disc, the menu items may differ and this menu may not be available.

HT-C9930_ELS_0914.indd 49 2010-09-14 6:53:18

Using the Title Menu

DVD-VIDEO



1. During playback, press the **TITLE MENU** button on the remote control.
2. Press the ▲▼◄ ► buttons to make the desired selection, then press the **ENTER** button.

✎ **NOTE**

- Depending on the disc, the menu items may differ and this menu may not be available.
- The Title Menu will only be displayed if there are at least two titles on the disc.

Playing the Title List

BD-RE/-R



1. During playback, press the **DISC MENU** or **TITLE MENU** button.
2. Press the ▲▼ buttons to select an entry you want to play from Title List, then press the **ENTER** button.

Using the Popup Menu

BD-ROM



1. During playback, press the **POPUP** button on the remote control.
2. Press the ▲▼◄ ► buttons or **ENTER** button to select the desired menu.

✎ **NOTE**

- Depending on the disc, the menu items may differ and this menu may not be available.

Using the Search and Skip Functions

During playback, you can search quickly through a chapter or track, and use the skip function to jump to the next selection.

Searching for a Desired Scene

BD-ROM BD-RE/-R DVD-VIDEO DVD±RW/±R DivX/MKV/MP4

- During playback, press the **SEARCH** (◀◀ ▶▶) button.
  Each time you press the **SEARCH** (◀◀ ▶▶) button, the playback speed will change as follows.

BD-ROM, BD-RE/-R, DVD-RW/-R, DVD+RW/+R, DVD-VIDEO	▶▶ 1 → ▶▶ 2 → ▶▶ 3 → ▶▶ 4 → ▶▶ 5 → ▶▶ 6 → ▶▶ 7 ◀◀ 1 → ◀◀ 2 → ◀◀ 3 → ◀◀ 4 → ◀◀ 5 → ◀◀ 6 → ◀◀ 7
DivX, MKV, MP4	▶▶ 1 → ▶▶ 2 → ▶▶ 3 ◀◀ 1 → ◀◀ 2 → ◀◀ 3

- To return to normal speed playback, press the **PLAY** (▶) button.

✎ **NOTE**

- No sound is heard during search mode.

Skipping Chapters

BD-ROM BD-RE/-R DVD-VIDEO DVD±RW/±R DivX/MKV/MP4

- During playback, press the **SKIP** (I◀◀ ▶▶I) button.
  If you press the **SKIP** (▶▶I) button, it moves to the next chapter.
  If you press the **SKIP** (I◀◀) button, it moves to the beginning of the chapter. One more press makes it move to the beginning of the previous chapter.

HT-C9930_ELS_0914.indd 50 2010-09-14 6:53:18

Slow Motion Play/Step Motion Play

Slow Motion Play

BD-ROM BD-RE/-R DVD-VIDEO DVD±RW/±R DivX/MKV/MP4

- In pause mode, press the **SEARCH** (▶▶) button.
  If you press the **SEARCH** (▶▶) button, the playback speed is reduced to
  ▮▶ 1/8 ▮▶ 1/4 ▮▶ 1/2
- To return to normal speed playback, press the **PLAY** (▶) button.

NOTE

- No sound is heard during slow mode.
- Slow motion operates only in the forward direction.

Step Motion Play

BD-ROM BD-RE/-R DVD-VIDEO DVD±RW/±R DivX/MKV/MP4

- In pause mode, press the **PAUSE** (❚❚) button. Each time the **PAUSE** (❚❚) button is pressed, a new frame will be appear.
- To return to normal speed playback, press the **PLAY** (▶) button.

NOTE


- No sound is heard during step mode.
- Step motion operates only in the forward direction.

Repeat Playback

Repeat the Title or Chapter

BD-ROM BD-RE/-R DVD-VIDEO DVD±RW/±R

Repeat the disc title or chapter.



1. During playback, press the **REPEAT** button on the remote control.
2. Press the ▲▼ buttons to select **Chapter** or **Title**, then press the **ENTER** button.




3. To return to normal play, press the **REPEAT** button again.
4. Press the ▲▼ buttons to select **Off**, the press the **ENTER** button.

NOTE

- Depending on the disc, the Repeat function may not be available.

Repeat the Section

BD-ROM BD-RE/-R DVD-VIDEO DVD±RW/±R



1. During playback, press the **REPEAT** button on the remote control.
2. Press the ▲▼ buttons to select **REPEAT A-B**.



3. Press the **ENTER** button at the point where you want repeat play to start (A).
4. Press the **ENTER** button at the point where you want repeat play to stop (B).
5. To return to normal play, press the **REPEAT** button again.
6. Press the **ENTER** button.

NOTE

- If you set point (B) before 5 seconds has lapsed, "Not Available" message will appear.


HT-C9930_ELS_0914.indd 51 2010-09-14 6:53:18

Using the TOOLS button

During playback, you can operate disc menu by pressing the **TOOLS** button.



• TOOLS Menu Screen



NOTE

- Depending on the disc, the TOOLS menu may differ.

Moving to a Desired Scene Directly

BD-ROM BD-RE/-R DVD-VIDEO DVD+RW/+R

1. During playback, press the **TOOLS** button.
2. Press the ▲▼ buttons to select **Title**, **Chapter** or **Playing Time**.
3. Enter the desired **Title**, **Chapter** or **Playing Time** using the number buttons, then press the **ENTER** button.

Selecting the Audio Language

BD-ROM BD-RE/-R DVD-VIDEO DivX/MKV/MP4

1. During playback, press the **TOOLS** button.
2. Press the ▲▼ buttons to select **Audio**.
3. Press the **ENTER** button.
4. Press the ▲▼ buttons to select the desired audio language.

NOTE

- The ◀▶ indicator will not be displayed on the screen if the BONUSVIEW section does not contain any BONUSVIEW audio settings.
- Information about the primary / secondary mode will be also displayed if the Blu-ray Disc has a BONUSVIEW section. Use the ◀▶ button to switch between primary and secondary audio modes.
- This function depends on what audio languages are encoded on the disc and may not be available.
- A Blu-ray Disc can contain up to 32 audio languages and a DVD up to 8.
- Some Blu-ray Discs may allow you to select either the multi-channel LPCM or Dolby digital audio soundtrack in English.

Selecting the Subtitle Language

BD-ROM DVD-VIDEO DivX/MKV/MP4

1. During playback, press the **TOOLS** button.
2. Press the ▲▼ buttons to select **Subtitle**.
3. Press the ◀▶ buttons to select the desired subtitle language.

NOTE

- Depending on the Blu-ray Disc / DVD, you may be able to change the desired subtitle in the Disc Menu. Press the **DISC MENU** button.
- This function depends on what subtitles are encoded on the disc and may not be available on all Blu-ray Discs/DVDs.
- A Blu-ray Disc can contain up to 255 subtitle languages and a DVD up to 32.
- Information about the primary / secondary mode will also be displayed if the Blu-ray Disc has a BONUSVIEW section.
- This function changes both the primary and secondary subtitles at the same time.
- The total number of subtitles is the sum of the primary and secondary ones.

HT-C9930_ELS_0914.indd 52 2010-09-14 6:53:24

Caption Function

DivX/MKV/MP4

- You must have some experience with video extraction and editing in order to use this feature properly.
- To use the caption function, save the caption file (*.smi) in the same file name as that of the DivX media file (*.avi) within the same folder.
  Example. Root Samsung_007CD1.avi
  Samsung_007CD1.smi
- Up to 60 alphanumeric characters or 30 East Asian characters (2 byte characters such as Korean and Chinese) for the file name.

Changing the Camera Angle

BD-ROM DVD-VIDEO

When a Blu-ray Disc/DVD contains multiple angles of a particular scene, you can use the ANGLE function.

1. During playback, press the **TOOLS** button.
2. Press the ▲▼ buttons to select **Angle**.
3. Press the ◄► buttons to select the desired Angle.

Selecting the Picture Setting

BD-ROM BD-RE/-R DVD-VIDEO DVD+RW/+R

This function enables you to adjust video quality when you are connected to a TV via HDMI.

1. During playback, press the **TOOLS** button.
2. Press the ▲▼ buttons to select **Picture Setting**, then press the **ENTER** button.
3. Press the ◄► buttons to select the desired **Picture Setting**, then press the **ENTER** button.
   - **Dynamic** : Choose this setting to increase Sharpness.
   - **Normal** : Choose this setting for most viewing applications.
   - **Movie** : This is the best setting for watching movies.
   - **User** : The user can adjust the sharpness and noise reduction function respectively.

Setting the BONUSVIEW

BD-ROM


The BONUSVIEW feature allows you to view additional content (such as commentaries) in a small screen window while the movie is playing. This function is only available if the disc has the bonusview feature.



1. During playback, press the **TOOLS** button.
2. Press the ▲▼ buttons to select **BONUSVIEW Video** or **BONUSVIEW Audio**.
3. Press the ◄► buttons to select the desired bonusview.

NOTE

- If you switch from BONUSVIEW Video, BONUSVIEW Audio will change automatically in accordance with BONUSVIEW Video.




HT-C9930_ELS_0914.indd 53 2010-09-14 6:53:31

Listening to Music

Audio CD MP3/WMA

Buttons on the Remote Control used for Music Playback




❶	**REPEAT** buttons : Selects the play mode in the Playlist.
❷	**SEARCH** buttons : Fast Play. (Audio CD (CD-DA) only)
❸	**PAUSE** button : Pauses playback.
❹	**PLAY** button : Plays the currently selected track.
❺	▲▼ buttons : Selects a track in the Music List or Playlist.
❻	**YELLOW(C)** button : Select or deselect a track in the music list.
❼	**ENTER** button : Plays and pauses the selected track.
❽	◀▶ buttons : Fast Play. (except for Audio CD (CD-DA))
❾	**STOP** button : Stops a track.
❿	**SKIP**(▶▶I) button : During playback, moves to the next page in the Music List or moves to the next track in the Playlist.
⓫	**SKIP** (I◀◀)button : During playback, moves to the previous page in the Music List or moves to the previous track in the Playlist. If you press this button after three seconds of playback in the Playlist, the current track will be replayed from the beginning. But, if you press this button within three seconds after playback starts in the Playlist, the previous track will be played.
⓬	**NUMBER** button : During the Playlist playback, press the desired track number. The selected track will be played.

HT-C9930_ELS_0914.indd 54 2010-09-14 6:53:32

Playing an Audio CD (CD-DA)/MP3

1. Insert an Audio CD (CD-DA) or an MP3 Disc into the disc tray.
   - For an Audio CD (CD-DA), the first track will be played automatically.
   - For an MP3 disc, press the ◄► buttons to select **Music**, then press the **ENTER** button.

Audio CD (CD-DA)/MP3 Screen Elements




❶	Displays the music information.
❷	Displays the playlist.
❸	Shows the current track/total tracks.
❹	Displays buttons available.
❺	Shows the current play time/total play time.
❻	Displays the current playback status.
❼	Displays the repeated playback status.

2. Press the ▲▼ buttons to select the track you want to play, and then press the **ENTER** button.

Repeat an Audio CD (CD-DA)/MP3

1. During the Playlist playback, press the **REPEAT** button.
2. Select the desired play mode by pressing the **REPEAT** button repeatedly.



Off	Audio CD (CD-DA)/MP3	Tracks on a disc are played in the order in which they were recorded on the disc.
(↻) Track	Audio CD (CD-DA)	Current track is repeated.
(↻) One	MP3	Current track is repeated.
(↻) All	Audio CD (CD-DA)/MP3	All tracks are repeated.
(⤮)Shuffle	Audio CD (CD-DA)/MP3	The random option plays a disc's track in random order.

Playlist

1. Insert an Audio CD (CD-DA) or an MP3 Disc into the disc tray.
   - For an Audio CD (CD-DA), the first track will be played automatically.
   - For an MP3 disc, press the ◄► buttons to select **Music**, then press the **ENTER** button.
2. To move to the Music List, press the **STOP** (■) or **RETURN** button.
   The Music List screen is displayed.
3. Press the ▲▼◄► buttons to move to the desired track, then press the **YELLOW(C)** button to check desired tracks.
   Repeat this procedure to select additional tracks.



HT-C9930_ELS_0914.indd 55 2010-09-14 6:53:34

4. If there is an undesired track in the playlist, press the **YELLOW(C)** button again. The selected track will be deleted.
5. Press the **ENTER** button to play the selected tracks.



6. To go to the Music List, press the **STOP** (■) or **RETURN** button.
7. To go to the Playlist, press the **ENTER** button.

NOTE


- You can create a playlist with up to 99 tracks on Audio CD (CD-DA).

Sound Mode

DSP(Digital Signal Processor) Function

This will regulate and stabilize the volume level against a drastic volume change when changing channels or during a scene transition.

Press the **DSP** button.



SMART SOUND → MP3 ENHANCE → POWER BASS → DSP OFF

- **SMART SOUND** : This will regulate and stabilize the volume level against a drastic volume change when changing channels or during a scene transition.
- **MP3 ENHANCE** : This also helps enhance your sound experience (ex. mp3 music). You can upscale your MP3 level sound(24 kHz, 8bit) to CD level sound(44.1 kHz, 16bit).
- **POWER BASS** : This function stresses low tones providing thudding sound effects.

V-SOUND (Virtual Sound)

Produces realistic sound through 3.1 channel audio system with the aid of virtual effects, this gives you the feeling you are listening to 5.1 channel audio system.

Press the **V-SOUND** button.



Each time the button is pressed, the selection changes as follows :

V.SOUND ON → V.SOUND OFF

S/W LEVEL

You can adjust the subwoofer's level.



HT-C9930_ELS_0914.indd 56 2010-09-14 6:53:38

Playing back a Picture

JPEG

Playing a JPEG Disc

1. Insert a JPEG disc into the disc tray.
2. Press the ◄► buttons to select the **Photos**, and then press the **ENTER** button.
3. Press the ▲▼◄► buttons to select the folder you want to play, and then press the **ENTER** button.
4. Press the ▲▼◄► buttons to select the photo you want to play, and then press the **ENTER** button.


NOTE

- You can't enlarge the subtitle and PG graphic in the full screen mode.

Using the TOOLS button

During the slide show playback, you can use various function by pressing the **TOOLS** button.





- **Stop Slide Show** : Select this if you want to stop the slide show.
- **Slide Show Speed** : Select this if you want to adjust the Slide Show speed.
- **Slide Show Effect** : Select if you want to set the Slide Show Effect.
- **Background Music** : Select this if you want to listen to music while viewing a picture.
- **Zoom** : Select this if you want to enlarge the current picture. (Enlarged up to 4 times)
- **Rotate** : Select this if you to rotate the picture. (This will rotate the picture either clockwise or counter clockwise.)
- **Information** : Shows the picture information including the name and size, etc.

NOTE

- Before you can enable the background music function, the photo file should exist in the same storage media with the music file. However, the sound quality can be affected by the bit rate of the MP3 file, the size of the photo and the encoding method.

HT-C9930_ELS_0914.indd 57 2010-09-14 6:53:39

Playing back a USB Storage

You can use the USB connection to play multimedia files (MP3, JPEG, DivX, etc) downloaded from the USB storage device.

1. Move to the home menu.
2. In Stop mode, connect the USB storage device to the USB port on the rear panel of the product. The message “Do you want to access the device?” will be displayed.
3. Press the ◄► button to select **Yes**, then press the **ENTER** button.
4. Press the **RED(A)** button.



5. Press the ▲▼ buttons to select the USB, then press the **ENTER** button.
6. Press the ◄► buttons to select the desired Videos, Music or Photos, then press the **ENTER** button.

4-1. Press the **BLUE(D)** button.



5-1. Press the ◄► buttons to select the USB, then press the **ENTER** button.

6-1. Press the ▲▼ buttons to select the desired Videos, Music or Photos, then press the **ENTER** button.

7. For playing back Video, Music or Photos files, see pages 49~57.

NOTE

- You must remove the USB storage device safely (by performing the “Safe to Remove Hardware” function) in order to prevent a possible damage to the USB memory. Press the **MENU** button to move to the main screen, and select the **YELLOW(C)** button and press the **ENTER** button.
- When the Audio-CD (CD-DA), MP3 and JPEG files are in stop mode, you can't see full screen by pressing the **FULL SCREEN** button on the remote control.
- If you insert the disc when playing a USB storage device, the device mode is changed to “DVD or CD” automatically.

HT-C9930_ELS_0914.indd 58 2010-09-14 6:53:46


Listening to Radio

Using buttons on the Remote Control

1. Press the **FUNCTION** button to select **TUNER**.
2. Tune in to the desired station.
   - **Automatic Tuning 1** : When the ⏮ ⏭ button is pressed, a preset broadcast station is selected.
   - **Automatic Tuning 2** : Press and hold the **TUNING/CH** (∧∨) button to automatically search for active broadcasting stations.
   - **Manual Tuning** : Press the **TUNING/CH** (∧∨) button to increase or decrease the frequency incrementally.

Setting Mono/Stereo

Press the **MO/ST** button.




- Each time the button is pressed, the sound switches between **STEREO** and **MONO**.
- In a poor reception area, select **MONO** for a clear, interference-free broadcast.

Presetting Stations

Example : Presetting FM 89.10 into memory

1. Press the **FUNCTION** button to select **TUNER**.
2. Press the **TUNING/CH** (∧∨) button to select <89.10>.
3. Press the **TUNER MEMORY** button.
   - NUMBER flashes on the display.
4. Press the ⏮ ⏭ button to select preset number.
   - You can select between 1 and 15 presets.
5. Press the **TUNER MEMORY** button again.
   - Press the **TUNER MEMORY** button before NUMBER disappears from the display.
   - NUMBER disappears from the display and the station is stored in memory.
6. To preset another station, repeat steps 2 to 5.
   - To tune in to a preset station, press the ⏮ ⏭ button on the remote control to select a channel.




Use iPod/iPhone with a Wireless Dock Cradle for iPod/iPhone

You can enjoy finer quality of music through the speaker by sending iPod/iPhone's audio signal using a Wireless Transmitter.

The Wireless Transmitter's linking ID is preset at the factory and the main unit and Wireless Transmitter should link (connect wirelessly) automatically when main unit is turned on. If the link indicator does not light when main unit and Wireless Transmitter are turned on, ID setting must be made manually. (See page 60)

Turn on the main unit and connect the iPod/iPhone to the Wireless transmitter.
Then press the **FUNC.** button on the product to select "**iPod**" mode.
The **FUNC.** mode of the main unit will switches as follows. Repeatedly press **BD/DVD → D.IN → AUX → iPod → HDMI 1 → HDMI 2 → TUNER** (See page 14)

How to charge the Wireless Transmitter



1. Connect the Wireless Transmitter to the Charging Cradle.
2. Connect the DC power adaptor to a wall socket.
   - The charging indicator lights up and charging starts. After the battery is fully charged, the charging indicator turns Green.

Operation status of the charging cradle's LED

Display	Function
GREEN LED ON	Power on /Charging completed
RED LED ON	Charging.

HT-C9930_ELS_0914.indd 59 2010-09-14 6:53:50

NOTE

- The indication is the charging state of the built-in battery in iPod main Dock.
  Check the charging state of iPod/iPhone by checking the charging indication of its battery.

! CAUTION

- **The Wireless Transmitter can be only charghed by the supplied adaptor.**

iPod/iPhone models that can be used with this product


- iPod touch (3rd generation)
- iPod touch (2nd generation)
- iPod touch (1st generation)
- iPod classic
- iPod with video
- iPod with dock connector
- iPod with Click Wheel
- iPod nano (5th generation)
- iPod nano (4th generation)
- iPod nano (3rd generation)
- iPod nano (2nd generation)
- iPod nano (1st generation)
- iPhone 3GS
- iPhone 3G
- iPhone

NOTE


- "Made for iPod" means that an electronic accessory has been designed to connect specifically to iPod and has been certified by the developer to meet Apple performance standards.
- "Made for iPhone" means that an electronic accessory has been designed to connect specifically to iPhone and has been certified by the developer to meet Apple performance standards.
- Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.
- The volume control may not be operated normally except at the referred models. If there is any error happened at the models above, please update the software of iPod/iPhone at the lastest version.

How to Link the Wireless Transmitter with the Main Unit

1. With the product turned off, insert the TX card into the TX Card Connection(WIRELESS) on the back of the Subwoofer.
   - Hold the TX card so that the label "WIRELESS" faces leftward and insert the card into the port.
   - The TX card enables communication between the product and the Wireless Transmitter.



2. Turn off your Home Cinema.
3. Press the **4**, **7**, **6**, **3** buttons on the remote control in order.
   - The Power LED will blink once.
4. Connect the iPod/iPhone to the Wireless transmitter.




5. Turn on the iPod/iPhone. Press the "**ID SET**" button on the back of the Wireless transmitter for 5 seconds. The link light on the wireless transmitter will blink fast.

HT-C9930_ELS_0914.indd 60 2010-09-14 6:53:54


6. Turn on your product.

- To listen to music from iPod/iPhone over the product, press the **FUNC.** button on the product to select "**iPod**" mode.



- After you select "**iPod**" mode, turn the volume of the product down to avoid hearing damage.
- You can control the speaker volume of iPod/iPhone with a volume wheel or a volume bar.
- When iPod/iPhone is stopped or in a power saving mode, a Wireless transmitter is turned to the Sleep Mode.
  When iPod/iPhone is turned to the Deep Sleep Mode, the Wireless transmitter is off.

Operation status of the wireless transmitter's LED



Display	Function	
	LINK (Blue LED)	STANDBY (Red LED)
LED ON	Pairing successfully completed	STANDBY
LED BLINK (Long blink)	Processing iPod/iPhone	LOW BATTERY
LED BLINK (Short blink)	Processing pairing	Pairing failed

! CAUTION

- If you use the main unit nearby a wireless device such as a laptop computer, an AP, or Wifi, any unstable operation error can happen.
- Do not insert any other card except the TX card dedicated to the product. If a different TX card is used, the product may be damaged or the card may not be removed easily.
- Do not insert the TX card or in the reverse direction.
- Insert the TX card when the product is turned off. Inserting the card when it is turned on may cause a problem.
- The transmission distance from the product to the wireless transmitter is about 5m, but may vary depending on your operation environment.
- The audio signal may be weakened or even lost where there exists an obstacle such as a wall or partition between the product and wireless transmitter or if you move around carrying the wireless transmitter.

HT-C9930_ELS_0914.indd 61 2010-09-14 6:54:02

Network Services

You can enjoy various network services such as Internet@TV or BD-LIVE by connecting the product to the network system.

Check the following instructions before using any network service.

1. Connect the product to the network. (see pages 30~31)
2. Configure the network settings. (see pages 43~46)

Using Internet@TV

Connect this product to the network to download various for a fee or free-of-charge applications. Internet@TV brings useful and entertaining content and services directly from the web to your product such as news, weather forecasts, stock market quotes, games, movies and music.

You can also initiate this function by pressing the **INTERNET@** button on the remote control.




Getting Started with Internet@TV

1. Move to the home menu.



2. Press the ◄► buttons to select **Internet@ TV** and press the **ENTER** button.
3. In the start screen of the Internet@TV service, you will see the service agreement screen. You must agree to the service terms and conditions before you can use the Internet@TV service.
4. After you have signed off on the service agreement, the Internet@TV service starts updating. It takes several minutes. When the update is complete, you will see the Internet@TV menu screen.

Internet@TV at a Glance




1	**Commercial** : Displays Internet@TV Guide, product introduction and new application introduction.
2	**Recommended** : Displays recommended contents managed by Samsung.
3	**My Application** : Displays your personal gallery which can be added and deleted by you.
4	**Navigation Help** : Displays remote control buttons available. • **RED(A)** : To log in to to Internet@TV. • **GREEN(B)** : To mark the application as a favourite. • **BLUE(D)** : To sort the applications. • **Return** : To return to the previous menu.
5	**Settings** : You can set the system setup and create accounts, etc.
6	**Samsung AppS** : You can download various chargeable or free-of-charge application services.

HT-C9930_ELS_0914.indd 62 2010-09-14 6:54:03

Using the Keypad

Through your remote, you can use the On-Screen Keypad in several Internet@TV applications to enter text.

Pressing the **FULL SCREEN** button on the remote while you are using the Screen Keypad lets you to change the text fields to lower case, upper case, numbers and icons.



❶	The current keypad. Use to enter characters.
❷	Press the **FULL SCREEN** button on the remote control to shift the input mode. : ab, Ab, AB, numbers or icons.
❸	Displays the current input mode.
❹	Press the **GREEN (B)** button on the remote control to change the input method. (T9 or ABC)
❺	Press the **TOOLS** button on the remote control to change the language.
❻	Press the **REPEAT** button on the remote control to delete a character.

For example, here is how to search an address in Google Maps:

1. Press the **ENTER** button on the remote at the Google Maps icon at the Internet@TV.
2. Press the **GREEN(B)** button to use the SEARCH function.
3. Press the ◄► buttons to move to the "Search or address" window.
4. Press the **ENTER** button to use Search or address function.
5. For example, suppose that you want to input "105 Challenger Rd., Ridgefield Park NJ'.
6. Press the **FULL SCREEN** button on the remote twice to change the input mode from lower case to numbers.
7. Press '1', '0', '5'.
8. Press the **YELLOW(C)** button on the remote to input a blank space.
9. Press the **FULL SCREEN** button on the remote 3 times to change the input mode from numbers to upper case.
10. Press '**2**' button on the remote 3 times to input **C**.
11. Press the **FULL SCREEN** button on the remote 3 times to change the input mode from upper case to lower case.
12. Press buttons on the remote to input the rest of 'Challenger Rd., Ridgefield Park NJ'.
13. Press the **ENTER** button.
14. The map and address appear on the screen.

✎ NOTE

- Samsung Electronics shall take no legal responsibility for any interruption of the Internet@TV service caused by the service provider for any reasons.
- The Internet@TV service is to download and process data via the Internet so that you can enjoy the contents on the TV screen.
  If the Internet connection is unstable, the service may be delayed or interrupted. Furthermore, the product may be turned off automatically.
  If this is the case, check the Internet connection and try again.
- The application service may be provided in English only and the contents available may vary, depending on the area.
- For more information about the Internet@TV service, visit the web site of the applicable service provider.
- The services provided are subject to change, depending on the Internet@TV service provider.
- The Internet@TV service contents may differ according to the firmware version.

HT-C9930_ELS_0928.indd 63 2010-09-28 1:52:24

Starting Internet@TV for the First Time

To start up Internet@TV for the first time, follow these steps:

1. Access Internet@TV as described on the previous page. The Internet@TV screen appears. In most cases, immediately after, the Country screen appears.
2. If the Country screen has appeared, use the ▲▼◄►buttons to select your country. When done, press Enter.

✎ **NOTE**

- Certain applications are available only in certain countries.

3. The General Disclaimer screen appears. Use the ◄► buttons to move to Agree, and then press Enter.

✎ **NOTE**

- Screens can take a few seconds to appear.

4. The Internet Privacy Policy screen appears. Use the ◄► buttons to move to Agree, and then press Enter.
5. The Service Update screen appears and installs a number of services and applications. When done, it closes. The applications and services downloaded are listed on the Internet@TV screen.

✎ **NOTE**

- Internet@TV may close momentarily during the installation process.
- A number of screens appear after installation. You can press Enter to close them or let them close on their own.


6. To start an application, use the ▲▼◄► buttons to highlight the application, and then press Enter. The application starts.

Account Login

For a more enjoyable application experience, register and log in to your account.


To do this, you must create an account first. (For instructions on creating an account, refer to Internet@TV ID on page 65.)

1. Press the ▲▼◄► buttons to select the desired application and press the **RED (A)** button.
2. Enter your user account and password.



Settings

Create IDs and configure Internet@TV settings from this screen.



System Setup

Reset

Resets Internet@TV settings to factory default settings.

✎ **NOTE**

- If you forgot your password, press the **STOP** (■) button on the front panel of the product for more than 5 seconds with no disc inserted.

HT-C9930_ELS_0914.indd 64 2010-09-14 6:54:09

Internet@TV ID

Use this menu to create or delete an account and enter or delete account information.

You can control your account including contents site's account information.

This account is only for Internet@TV.

Create

Create an account and link it with desired service applications.

NOTE

- The account name must be at least 1 character in length but no more than 8.
- You can register up to 10 User Account Names.

Manager

- **Service Site** : Register login information for service sites.
- **Change Password** : Change account password.
- **Delete** : Delete the account.

Service Manager

Delete and lock applications installed to Internet@TV.

Lock

Lock the application. Accessing a locked application requires the password.

Delete


Delete the application.

Properties

Display information about Internet@TV. Use the Check the speed of your internet connection option to test your network connection.

Samsung AppS

Various applications are available from here, organized into different categories. Some applications have a download fee.



My Applications

Displays the application list.

Help

If you questions about Internet@TV, check this section first. If none of the tips apply, please visit the help website.

Using the colour buttons with the Samsung Apps

- **RED(A) (Login)** : To log in to the internet service.
- **GREEN(B) (Thumbnail View)** : To change the view mode.
- **BLUE(D) (Sort By)** : To sort the applications by Featured, Most Downloaded, Most Recent or Name.

Internet@TV Services Available

- YouTube : You can view video streamed by YouTube.

NOTE

- The available Internet contents service may be added or deleted.

HT-C9930_ELS_0914.indd 65 2010-09-14 6:54:10

Network Services

BD-LIVE™

Once the product is connected to the network, you can enjoy various movie-related service contents using a BD-LIVE compliant disc.

1. Check the size of the remaining memory. The memory device must have at least 1GB of free space to accommodate the BD-LIVE services.
2. Insert a Blu-ray disc that supports BD-LIVE.
3. Select an item from various BD-LIVE service contents provided by the disc manufacturer.

NOTE

- The way you use BD-LIVE and the provided contents may differ, depending on the disc manufacturer.

Software Upgrade Notification

In network connection, the product will notice you of any new software version with a popup message.

1. Turn on the product.
2. From the Software Upgrade menu, set Auto Upgrade Notification to **On**. (See page 48) If there is a new software version available, the product will notice you with a popup message.
3. To upgrade the firmware, select **Yes**. It will turn off automatically before restarting. (Never turn it on manually.)
4. The update progress popup will appear. When the update is completed, it will turn back off automatically.
5. Press the **POWER** button to turn on the product.

NOTE


- Update will be completed when the product turns off after restarting. Press the **POWER** button to turn on the updated product for your use.
  Never turn off or on the product manually during the update process.
- Samsung Electronics shall take no legal responsibility for product malfunction caused by unstable of internet connection or consumer negligence during software upgrade.

Using the AllShare Function

AllShare enables you to play music, video and photo files in your PC using the product.

To use AllShare, you must connect the product to your PC via the network (See pages 30~31) and install the SAMSUNG PC Share Manager on the PC.

1. Visit the Samsung website at www.samsung.com.
2. Download the SAMSUNG PC Share Manager and install it on the PC.
3. When the installation is completed, you will see the SAMSUNG PC Share Manager icon on your desktop.
   Double-click the icon to launch the application.
4. Select a folder to share from the My computer pane, and click the **Share Folder Enabled icon** ( ).
   (To remove a shared folder : Select a folder to remove from the shared folders, and click the **Share Folder Disabled icon** ( ).)
5. To apply the updated sharing state to the server, click the **Set Change State icon** ( ).
6. To enable the product to locate a PC server, click **Share** from the menu bar.
   Click **Set Device Policy** and click **Accept**.



7. Click the **Set Change State icon** ( ) and move to the home menu on the product.

HT-C9930_ELS_0914.indd 66 2010-09-14 6:54:11


8. To select a device, use the **RED(A)** or **BLUE(D)** button to select a file to play. (For playing back Video, Music or Photos files, see pages 49~57.)



NOTE

- Depending on te performance of the external modem or router, HD video may not play properly.
- If your system uses a firewall, the product may not locate your PC on the TV screen.
- AllShare does not support the following functions.
  - The Background Music and Background Music Setting functions.
  - Sorting files by preference in the Photo, Music, and Movie folders.
  - The Change Group function.
  - The Safe Remove function.
- The Sorting method may differ depending on the sever function.
- The search and skip operation may differ depending on the sever function.
- During video playback, play time will not display.
- To use AllShare function, please locate both this product and PC in same subnet.

Application Program at a Glance



❶	**Menu Bar**
❷	**Share Folder Enabled icon** : Use this if you want to select a folder in your PC to share.
❸	**Share Folder Disabled icon** : Use this if you want to set folder sharing off.
❹	**Refresh icon** : Use this if you want to refresh list of folders and files in My Computer.
❺	**Set Change State icon** : Select a folder to share and don't forget to press this button. The updated state will be applied to the server.
❻	**Server** : Displays the name of the sharing server.
❼	**Shared Folder** : Displays a list of the shared folders.
❽	**My Computer** : Displays a list of the folders and files in the PC.

HT-C9930_ELS_0914.indd 67 2010-09-14 6:54:13

Other information

Troubleshooting

Refer to the chart below when this product does not function properly. If the problem you are experiencing is not listed below or if the instruction below does not help, turn off the product, disconnect the power cord and contact the nearest authorized dealer or Samsung Electronics Service Centre.

Symptom	Check/Remedy
I cannot eject the disc.	• Is the power cord plugged securely into the outlet? • Turn off the power and then turn it back on.
The iPod fails to connect.	• Check the condition of the Wireless Transmitter, Charging Cradle and DC power adaptor connection. • Keep the iPod S/W version up to date.
Playback does not start.	• Check the region number of the BD/DVD. BD/DVD discs purchased from abroad may not be playable. • CD-ROMs and DVD-ROMs cannot be played on this Product. • Make sure that the rating level is correct.
Playback does not start immediately when the Play/Pause button is pressed.	• Are you using a deformed disc or a disc with scratches on the surface? • Wipe the disc clean.
Sound is not produced.	• No sound is heard during fast playback, slow playback, and step motion playback. • Are the speakers connected properly? Is the speaker setup correctly customized? • Is the disc severely damaged?
Sound can be heard only from a few speakers and not all 4.	• On certain BD/DVD discs, sound is output from the front speakers only. • Check if the speakers are connected properly. • Adjust the volume.
The remote control does not work.	• Is the remote control being operated within its operation range of angle and distance? • Are the batteries drained? • Have you selected the mode(TV/BD) functions of the remote control (TV or BD) correctly?
• Disc is rotating but no picture is produced. **• Picture quality is poor and picture is shaking.**	• Is the TV power on? • Is the HDMI cable connected properly? • Is the disc dirty or damaged? • A poorly manufactured disc may not be playable.
Audio language and subtitles do not work.	• Audio language and subtitles will not work if the disc does not contain them.
Menu screen does not appear even when the menu function is selected.	• Are you using a disc that does not contain menus?

HT-C9930_ELS_0914.indd 68 2010-09-14 6:54:16

Symptom	Check/Remedy
Aspect ratio cannot be changed.	• You can play 16:9 BD/DVDs in 16:9 Wide mode, 4:3 Letter Box mode, or 4:3 Pan - Scan mode, but 4:3 BD/DVDs can be seen in 4:3 ratio only. Refer to the Blu-ray Disc jacket and then select the appropriate function.
• The product is not working. (Example: The power goes out or a strange noise is heard.) • The Product is not working normally.	• Press the **STOP** (■) button (on front panel) for more than 5 seconds with no disc inside. - Using the RESET function will erase all stored settings. Do not use this unless necessary.
The rating level password has been forgotten.	• With no disc in the product, press and hold the product's **STOP** (■) button for longer than 5 seconds. **INIT** appears on the display and all settings will return to the default values. And then press the **POWER** button. - Using the RESET function will erase all stored settings. Do not use this unless necessary.
Can't receive radio broadcasts.	• Is the antenna connected properly? • If the antenna's input signal is weak, install an external FM antenna in an area with good reception.
While listening to TV audio through the Product, no sound is heard.	• If the **EJECT** (⏏) button is pressed while listening to TV audio using the D.IN or AUX functions, the BD/DVD functions are turned on and the TV audio is muted.
"Not Available" appears on screen.	• The features or action cannot be completed at this time because: 1. The BD/DVD's software restricts it. 2. The BD/DVD's software doesn't support the feature (e.g., angles) 3. The feature is not available at the moment. 4. You've requested a title or chapter number or search time that is out of range.
If the HDMI output is set to a resolution your TV cannot support (for example, 1080p), you may not see a picture on your TV.	• Press the **STOP** (■) button (on front panel) for more than 5 seconds with no disc inside. All settings will revert to the factory settings. • When the factory default settings are restored, all the user data stored in the BD data will be deleted.
No HDMI output.	• Check the connection between the TV and the HDMI jack of the Product. • Check if your TV supports 576p(480p)/720p/1080i/1080p HDMI input resolution.
Abnormal HDMI output screen.	• If random noise appears on the screen, it means that TV does not support HDCP (High-bandwidth Digital Content Protection).

HT-C9930_ELS_0914.indd 69 2010-09-14 6:54:16

Other information

Symptom	Check/Remedy
PC Share Manager function	
I can see folders shared through the PC Share Manager, but I cannot see the files.	• Since it shows only files corresponding to the Image, Music, and Movie categories, files that do not correspond to these categories may not be displayed.
AllShare function	
Video is played intermittently.	• Check if the network is stable. • Check if the network cable is properly connected and if the network is not overloaded. • Wireless connection between the server and the product is unstable. Check the connection.
AllShare connection between TV and PC is unstable.	• IP address under the same subnetwork should be unique, otherwise IP collision can results in such a phenomenon. • Check if you have a firewall enabled. If so, disable the firewall function.
BD-LIVE	
I cannot connect to the BD-LIVE server.	• Check whether the network connection is successful or not by using Network Test menu. (See page 46) • Check whether the USB memory device is connected with product or not. • The memory device must have at least 1GB of free space to accommodate the BD-LIVE service. You can check the available size in BD Data Management. (See page 41) • Please check whether the BD-LIVE Internet Connection menu is set to Allow(All). • If all above fails, contact the contents provider or update the latest firmware.
When using the BD-LIVE service, an error occurs.	• The memory device must have at least 1GB of free space to accommodate the BD-LIVE service. You can check the available size in BD Data Management. (See page 41)

✎ **NOTE**

- When the factory default settings are restored, all the user data stored in the BD data will be deleted.

HT-C9930_ELS_0914.indd 70 2010-09-14 6:54:17

Specifications

General	Weight	2.26 kg	
	Dimensions	490 (W) x 163.5 (H) x 29 (D) mm	
	Operating Temperature Range	+5°C to +35°C	
	Operating Humidity Range	10 % to 75 %	
FM Tuner	Signal/noise ratio	70 dB	
	Usable sensitivity	10 dB	
	Total harmonic distortion	0.5 %	
Disc	BD (Blu-ray Disc)	Reading Speed : 4.917m/sec	
	DVD (Digital Versatile Disc)	Reading Speed : 3.49 ~ 4.06 m/sec.	
		Approx. Play Time (Single Sided, Single Layer Disc) : 135 min.	
	CD : 12cm (COMPACT DISC)	Reading Speed : 4.8 ~ 5.6 m/sec.	
		Maximum Play Time : 74 min.	
	CD : 8cm (COMPACT DISC)	Reading Speed : 4.8 ~ 5.6 m/sec.	
		Maximum Play Time : 20 min.	
Video/Audio	HDMI	2D : 1080p, 1080i, 720p, 576p(480p) 3D : 1080p, 720p	
		PCM multichannel audio, Bitstream audio, PCM audio	
Amplifier	Front speaker output	165W x 2(3Ω)	
	Centre speaker output	170W(3Ω)	
	Subwoofer speaker output	240W(3Ω)	
	Frequency response	Analogue input	20Hz~20kHz (±3dB)
		Digital input	20Hz~44kHz (±3dB)
	S/N Ratio	70dB	
	Channel separation	60dB	
	Input sensitivity	(AUX)500mV	

HT-C9930_ELS_0914.indd 71 2010-09-14 6:54:17

Other information

Speaker	Speaker system	3.1ch speaker system		
		Front	Centre	Subwoofer
	Impedance	3 Ω	3 Ω	3 Ω
	Frequency range	140Hz~20kHz	140Hz~20kHz	40Hz ~ 160Hz
	Output sound pressure level	86dB/W/M	86dB/W/M	88dB/W/M
	Rated input	165W	170W	240W
	Maximum input	330W	340W	480W
	Dimensions (W x H x D)	Front : 94 x 1300 x 90 mm (Stand base : ø 308 mm) Centre : 361 x 73 x 53 mm Subwoofer : 219 x 443 x 445 mm		
	Weights	Front : 4.0 kg, Centre : 0.45 kg , Subwoofer : 12.6 kg		

*: Nominal specification

- Samsung Electronics Co., Ltd reserves the right to change the specifications without notice.
- Weight and dimensions are approximate.
- Design and specifications are subject to change without prior notice.
- For the power supply and Power Consumption, refer to the label attached to the product.

HT-WDC10

Weight	0.10 kg (total)
Dimensions (W x H x D)	Wireless Transmitter : 40.6 x 89 x 28 mm Charging Cradle : 51 x 28 x 51 mm
Operating Temperature Range	+5°C to +35°C
Operating Humidity Range	10% ~ 75%
Charging time	90min ± 10min
Available running time	180min ± 30min (The time may differ under the condition of the iPod or the iPhone)

HT-C9930_ELS_0914.indd 72 2010-09-14 6:54:17

Contact SAMSUNG WORLD WIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care centre.

Area	Contact Centre ☎	Web Site
▪ North America		
Canada	1-800-SAMSUNG (726-7864)	www.samsung.com
Mexico	01-800-SAMSUNG (726-7864)	www.samsung.com
U.S.A	1-800-SAMSUNG (726-7864)	www.samsung.com
▪ Latin America		
Argentine	0800-333-3733	www.samsung.com
Brazil	0800-124-421 / 4004-0000	www.samsung.com
Chile	800-SAMSUNG (726-7864)	www.samsung.com
Colombia	01-8000112112	www.samsung.com
Costa Rica	0-800-507-7267	www.samsung.com
Dominica	1-800-751-2676	www.samsung.com
Ecuador	1-800-10-7267	www.samsung.com
El Salvador	800-6225	www.samsung.com
Guatemala	1-800-299-0013	www.samsung.com
Honduras	800-7919267	www.samsung.com
Jamaica	1-800-234-7267	www.samsung.com
Nicaragua	00-1800-5077267	www.samsung.com
Panama	800-7267	www.samsung.com
Peru	0-800-777-08	www.samsung.com
Puerto Rico	1-800-682-3180	www.samsung.com
Trinidad & Tobago	1-800-SAMSUNG (726-7864)	www.samsung.com
Venezuela	0-800-100-5303	www.samsung.com
▪ Europe		
Albania	42 27 5755	-
Austria	0810 - SAMSUNG (7267864, € 0.07/min)	www.samsung.com
Belgium	02-201-24-18	www.samsung.com/be (Dutch) www.samsung.com/be_fr (French)
Bosnia	05 133 1999	-
Bulgaria	07001 33 11	www.samsung.com
Croatia	062 SAMSUNG (062 726 7864)	www.samsung.com
Czech	800-SAMSUNG (800-726786) Samsung Zrt., česká organizační složka, Oasis Florenc, Sokolovská394/17, 180 00, Praha 8	www.samsung.com
Denmark	70 70 19 70	www.samsung.com
Finland	030 - 6227 515	www.samsung.com
France	01 48 63 00 00	www.samsung.com
Germany	01805 - SAMSUNG (726-7864 € 0,14/Min)	www.samsung.com
Hungary	06-80-SAMSUNG (726-7864)	www.samsung.com
Italia	800-SAMSUNG (726-7864)	www.samsung.com
Kosovo	+381 0113216899	-
Luxemburg	261 03 710	www.samsung.com
Macedonia	023 207 777	-
Montenegro	020 405 888	-
Netherlands	0900-SAMSUNG (0900-7267864) (€ 0,10/Min)	www.samsung.com
Norway	815-56 480	www.samsung.com
Poland	0 801 1SAMSUNG (172678) / 022-607-93-33	www.samsung.com
Portugal	80820-SAMSUNG (726-7864)	www.samsung.com
Rumania	1. 08010 SAMSUNG (72678) - doar din rețeaua Romtelecom, tarif local 2. 021.206.01.10 - din orice rețea, tarif normal	www.samsung.com
Serbia	0700 Samsung (0700 726 7864)	www.samsung.com
Slovakia	0800-SAMSUNG (726-7864)	www.samsung.com
Spain	902-1-SAMSUNG (902 172 678)	www.samsung.com
Sweden	0771 726 7864 (SAMSUNG)	www.samsung.com
Switzerland	0848-SAMSUNG (7267864, CHF 0.08/min)	www.samsung.com/ch www.samsung.com/ch_fr/(French)
U.K	0330 SAMSUNG (7267864)	www.samsung.com
Eire	0818 717100	www.samsung.com
Lithuania	8-800-77777	www.samsung.com
Latvia	8000-7267	www.samsung.com
Estonia	800-7267	www.samsung.com
▪ CIS		
Russia	8-800-555-55-55	www.samsung.com
Georgia	8-800-555-555	-
Armenia	0-800-05-555	-
Azerbaijan	088-55-55-555	-
Kazakhstan	8-10-800-500-55-500 (GSM: 7799)	www.samsung.com
Uzbekistan	8-10-800-500-55-500	www.samsung.com
Kyrgyzstan	00-800-500-55-500	www.samsung.com
Tadjikistan	8-10-800-500-55-500	www.samsung.com
Ukraine	0-800-502-000	www.samsung.ua www.samsung.com/ua_ru
Belarus	810-800-500-55-500	-
Moldova	00-800-500-55-500	-
▪ Asia Pacific		
Australia	1300 362 603	www.samsung.com
New Zealand	0800 SAMSUNG (0800 726 786)	www.samsung.com
China	400-810-5858 / 010-6475 1880	www.samsung.com
Hong Kong	(852) 3698 4698	www.samsung.com/hk www.samsung.com/hk_en/
India	3030 8282 / 1800 110011 / 1800 3000 8282 / 1800 266 8282	www.samsung.com
Indonesia	0800-112-8888 / 021-5699-7777	www.samsung.com
Japan	0120-327-527	www.samsung.com
Malaysia	1800-88-9999	www.samsung.com
Philippines	1-800-10-SAMSUNG(726-7864) / 1-800-3-SAMSUNG(726-7864) / 1-800-8-SAMSUNG(726-7864) / 02-5805777	www.samsung.com
Singapore	1800-SAMSUNG (726-7864)	www.samsung.com
Thailand	1800-29-3232 / 02-689-3232	www.samsung.com
Taiwan	0800-329-999	www.samsung.com
Vietnam	1 800 588 889	www.samsung.com
▪ Middle East		
Bahrain	8000-4726	www.samsung.com
Egypt	08000-726786	www.samsung.com
Jordan	800-22273	www.samsung.com
Morocco	080 100 2255	www.samsung.com
Oman	800-SAMSUNG (726-7864)	www.samsung.com
Saudi Arabia	9200-21230	www.samsung.com
Turkey	444 77 11	www.samsung.com
U.A.E	800-SAMSUNG (726-7864)	www.samsung.com
▪ Africa		
Nigeria	0800-SAMSUNG (726-7864)	www.samsung.com
South Africa	0860-SAMSUNG (726-7864)	www.samsung.com



Correct disposal of batteries in this product

(Applicable in the European Union and other European countries with separate battery return systems.)

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.

To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system.



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract.
This product and its electronic accessories should not be mixed with other commercial wastes for disposal.