NOKIA

Nokia 3310

User Guide

Issue 2018-04-19 en

About this user guide

Important: For important information on the safe use of your device and battery, read “For your safety” and “Product Safety” info in the printed user guide, or at www.nokia.com/support before you take the device into use. To find out how to get started with your new device, read the printed user guide.

© 2018 HMD Global Oy. All rights reserved.

Table of Contents

About this user guide 2
Get started 6
Keys and parts 6
Set up and switch on your phone 7
Charge your phone 11
Lock or unlock the keys 11
Basics 13
Get the most out of the two SIM cards 13
Explore your phone 13
Change the volume 17
Change your ring or message tone 18
Change the wallpaper 19
Write text 19
Calls, contacts, and messages 21
Calls 21
Contacts 21
Send and receive messages 22
Personalize your phone 24
Change your ring or message tone 24
Change the look of your home screen 24
Profiles 25
Settings for Go to 26
Camera 28
Photos 28
Videos 28
Internet and connections 30
Browse the web 30
Music and videos 31
Music player 31
Video player 31
Radio 33

© 2018 HMD Global Oy. All rights reserved.

Find and save radio stations 33
Listen to radio 33
Clock, calendar, and calculator 34
Set the time and date manually 34
Alarm clock 34
Calendar 34
Calculator 35
Bluetooth 36
Activate Bluetooth 36
Copy and remove content 37
Copy content 37
Share content 37
Remove private content from your phone 38
Backup and restore 39
Create a backup 39
Restore a backup 39
Settings 40
Call settings 40
Phone settings 40
Cost settings 40
Accessories 41
Security settings 41
Feedback 41
Restore factory settings 42
Message settings 42
Product and safety information 44
For your safety 44
Network services and costs 47
Emergency calls 47
Take care of your device 48
Recycle 48
Crossed-out wheelie bin symbol 49
Battery and charger information 49
Small children 51
Medical devices 51

© 2018 HMD Global Oy. All rights reserved.

Implanted medical devices 51
Hearing 52
Protect your device from harmful content 52
Vehicles 52
Potentially explosive environments 53
Certification information (SAR) 53
Copyrights and other notices 54
About Digital Rights Management 56
Frequently asked questions 57
How do I get help for my phone? 57
Where can I find the warranty terms for my phone? 57
How do I get my phone repaired or replaced? 57
What should I do if my phone is lost or stolen? 57
Where can I see the full range of Nokia phones? 57
Where can I buy a Nokia phone? 57
My phone won’t turn on, what should I do? 58
My phone won’t charge, what should I do? 58
Troubleshooting tips 58
Where can I get support for my Lumia smartphone? 59

© 2018 HMD Global Oy. All rights reserved.

Get started

Keys and parts

Explore the keys and parts of your new phone.

YOUR PHONE



The keys and parts of your phone are:

1. Charger connector
2. Earpiece
3. Number keys
4. Selection key
7. Headphone connector
8. Loudspeaker
9. Camera
10. Flash light

© 2018 HMD Global Oy. All rights reserved.

5. Function key, call key
6. Function key, end call/power key
11. Antenna area
12. Back cover opening slot

To lock the keys, select Go to > Lock keypad .

To unlock the keys, quickly press ⌒, and select Unlock .

Avoid touching the antenna area while the antenna is in use. Contact with antennas affects the communication quality and may reduce battery life due to higher power level during operation.

Do not connect to products that create an output signal, as this may damage the device. Do not connect any voltage source to the audio connector. If you connect an external device or headset, other than those approved for use with this device, to the audio connector, pay special attention to volume levels.
Parts of the device are magnetic. Metallic materials may be attracted to the device. Do not place credit cards or other magnetic storage media near the device, because info stored on them may be erased.

Some of the accessories mentioned in this user guide, such as charger, headset, or data cable, may be sold separately.

Note: You can set the phone to ask for a security code. The pre-set code is 12345. Change it to protect your privacy and personal data. Note, however, that when you change the code, you need to remember the new code, as HMD Global is not able to open or bypass it.

Set up and switch on your phone

Learn how to insert the SIM card, memory card, and battery, and how to switch on your phone.



© 2018 HMD Global Oy. All rights reserved.

MICRO SIM

Important: This device is designed to be used with a micro SIM card (see figure) only. Use of incompatible SIM cards may damage the card or the device, and may corrupt data stored on the card. Please consult your mobile operator for the use of a SIM card that has a nano-UICC cutout.



MICROSD MEMORY CARDS

Use only compatible memory cards approved for use with this device. Incompatible cards may damage the card and the device and corrupt data stored on the card.

Note: Switch the device off and disconnect the charger and any other device before removing any covers. Avoid touching electronic components while changing any covers. Always store and use the device with any covers attached.

© 2018 HMD Global Oy. All rights reserved.

SET UP YOUR PHONE (SINGLE SIM)



1. Place your fingernail in the small slot at the bottom of the phone, lift and remove the cover.
2. If the battery is in the phone, lift it out.
3. Slide the SIM into the SIM slot with the contact area face down.
4. If you have a memory card, slide the memory card into the memory card slot.
5. Line up the battery contacts, and put the battery in.
6. Replace the back cover.

© 2018 HMD Global Oy. All rights reserved.

SET UP YOUR PHONE (DUAL SIM)



1. Place your fingernail in the small slot at the bottom of the phone, lift and remove the cover.
2. If the battery is in the phone, lift it out.
3. Slide the first SIM into SIM slot 1 with the contact area face down. Slide the second SIM into SIM slot 2. Both SIM cards are available at the same time when the device is not being used, but while one SIM card is active, for example, making a call, the other may be unavailable.
4. If you have a memory card, slide the memory card into the memory card slot.
5. Line up the battery contacts, and put the battery in.
6. Replace the back cover.

SWITCH ON YOUR PHONE

Press and hold the ⏻ key.

REMOVE THE SIM CARD

Open the back cover, remove the battery, and slide the SIM out.

© 2018 HMD Global Oy. All rights reserved.

REMOVE THE MEMORY CARD

Open the back cover, remove the battery, and pull the memory card out.

Charge your phone

Your battery has been partially charged at the factory, but you may need to recharge it before you can use your phone.

CHARGE THE BATTERY

1. Plug the charger into a wall outlet.
2. Connect the charger to the phone. When done, unplug the charger from the phone, then from the wall outlet.

If the battery is completely discharged, it may take several minutes before the charging indicator is displayed.



Tip: You can use USB charging when a wall outlet is not available. Data can be transferred while charging the device. The efficiency of USB charging power varies significantly, and it may take a long time for charging to start and the device to start functioning. Make sure your computer is switched on.

SAVE POWER

To save power:

1. Charge wisely: always charge the battery fully.
2. Select only the sounds that you need: mute unnecessary sounds, such as keypad sounds.
3. Use wired headphones, rather than the loudspeaker.
4. Change the phone screen settings: set the phone screen to switch off after a short time.
5. Lower the screen brightness.
6. When applicable, use network connections, such as Bluetooth, selectively: switch the connections on only when you are using them.

© 2018 HMD Global Oy. All rights reserved.

Lock or unlock the keys

LOCK THE KEYPAD

To avoid accidentally pressing the keys, use keypad lock. Select Go to > Lock keypad .

UNLOCK THE KEYPAD

Press , and select Unlock .

© 2018 HMD Global Oy. All rights reserved.

Basics

Get the most out of the two SIM cards

Your phone can use two SIM cards, and you can use them for different purposes.

SELECT WHICH SIM CARD TO USE

1. Select Menu > ⚙ > Connectivity > Dual SIM .
2. To choose which SIM to use for calls, select Call , switch Always ask to Off , and select Preferred SIM .
3. To choose which SIM to use for messages, select Messaging , switch Always ask to Off , and select Preferred SIM .
4. To choose which SIM to use for mobile data, switch Mobile data connection to On , and select Mobile data > Preferred SIM .

FORWARD CALLS BETWEEN YOUR 2 SIMS

Get the most out of your 2 SIM cards. If you forward your calls between your SIMs, when someone calls you on one SIM while you're having a call on the other, you can manage your calls from both SIMs just like with only one SIM.

Make sure you have 2 SIM cards inserted in your phone.

1. Select Menu >  > SIM numbers .
2. Type in the numbers of your both SIMs.
3. Depending on how you want to forward the calls when one of your SIMs is out of reach or busy, select Between two SIMs , From SIM1 to SIM2 , or From SIM2 to SIM1 .



Tip: To check if your calls are being forwarded, select Check status .

© 2018 HMD Global Oy. All rights reserved.

Explore your phone

SEE THE APPS AND FEATURES OF YOUR PHONE



Select Menu .

© 2018 HMD Global Oy. All rights reserved.

GO TO AN APP OR FEATURE



Press the scroll key up, down, left, or right.

OPEN AN APP OR SELECT A FEATURE



Select Choose .

© 2018 HMD Global Oy. All rights reserved.

GO BACK TO THE PREVIOUS VIEW



Select Back .

GO BACK TO THE HOME SCREEN



Press the end key.

© 2018 HMD Global Oy. All rights reserved.

SWITCH ON THE FLASHLIGHT



On the idle screen, quickly scroll up twice to switch on the flashligt.

To switch off the flashlight, scroll up once.

Do not shine the light in anyone’s eyes.

© 2018 HMD Global Oy. All rights reserved.

Change the volume

TURN THE VOLUME UP OR DOWN



Trouble hearing your phone ringing in noisy environments, or calls too loud? You can change the volume to your liking.

Scroll up or down to change the volume during a call or when listening to the radio.

Change your ring or message tone

You can choose a new ringtone or message tone.

CHANGE YOUR RINGTONE

1. Select Menu > ⚙ > Tones .
2. Choose Ringtone .
3. Scroll to a ringtone.
4. Press OK .

© 2018 HMD Global Oy. All rights reserved.



Tip: Is your ringtone too loud or too silent? Select Ringtone volume and scroll left or right.

CHANGE YOUR MESSAGE TONES

1. Select Menu > ⚙ > Tones > Messages .
2. Scroll to a message tone.
3. Press OK .

Change the wallpaper

CHOOSE A NEW WALLPAPER

You can change the background of your home screen with Wallpaper setting.

1. Select Menu > ⚙ > Display settings > Wallpaper .
2. Select Default to see the available wallpapers.
3. Scroll to a wallpaper and select View to see how it looks on the screen.
4. Select Choose and then the option to position the wallpaper on the screen.

You can also select a wallpaper from the photos you have on your phone.

Write text

WRITE USING THE KEYPAD

Writing with the keypad is easy and fun.

Press a key repeatedly until the letter is shown.

To type in a space press 0 .

To type in a special character or punctuation mark, press * .

© 2018 HMD Global Oy. All rights reserved.

To switch between character cases, press # repeatedly.

To type in a number, press and hold a number key.

USE PREDICTIVE TEXT

To speed up your writing, your phone can guess what you are starting to write. Predictive text is based on a built-in dictionary. This feature is not available for all languages.

1. Select Options > Predictive text and the language.
2. Start writing a word. When the word you want is shown, press 0.

To change a word, press * repeatedly until the word you want is shown.

If the word you want isn't in the dictionary, write the word, press * repeatedly to skip all unwanted words, select Spell, and write the word. The word is added to the dictionary.

To switch between predictive and traditional text, press # repeatedly.

To switch predictive text off, select Options > Predictive text > Prediction off.

© 2018 HMD Global Oy. All rights reserved.

Calls, contacts, and messages

Calls

MAKE A CALL

Learn how to make a call with your new phone.

1. Type in the phone number. To type in the + character, used for international calls, press * twice.

2. Press . If asked, select which SIM to use.

3. To end the call, press .

ANSWER A CALL

Press .



Tip: To handle your calls hands-free, pair your phone with a compatible Bluetooth headset (sold separately). To switch Bluetooth on, select Menu > > Connectivity > Bluetooth, and switch Bluetooth to On.



Tip: If you are in a situation where you cannot answer the phone and you need to silence it quickly, select Silence.

© 2018 HMD Global Oy. All rights reserved.

Contacts

ADD A CONTACT

Save and organize your friends' phone numbers.

1. Select Menu > > Options > Add new contact .
2. Write the name, and type in the number.
3. Select Save .



Tip: You can select which memory you want to use for storing contacts. Select Options > > Memory .



Tip: To save a phone number in the dialer, type in the number, and select Save .

SAVE A CONTACT FROM CALL LOG

You can save contacts from call log.

1. Select Menu > > Received or Missed , depending on from where you want to save the contact.
2. Highlight the number you want to save, and select Options > Save .
3. Add the contact's name and Save .

CALL A CONTACT OR SEND A MESSAGE

Call a contact directly from the contacts list. You can also send messages from the contacts list.

1. Select Menu > and scroll to a contact you want to call or send a message.
2. Select the contact and select Call or Send message .

© 2018 HMD Global Oy. All rights reserved.

Send and receive messages

WRITE AND SEND MESSAGES

1. Select Menu > > Create message .
2. Select Add recipient to add a recipient. You can enter a phone number or add a recipient from either Contacts or Distribution lists .
3. Write a message on the Message field.
4. Select Send .

WRITING OPTIONS

You can find different options for writing a message, in Options when you are in the message field. You can insert smileys and symbols, or use ready-made templates. You can add images or discard messages, and save them as drafts.

You can also turn on the dictionary from Options .

MESSAGE OPTIONS

When you have received messages in your phone, scroll to a message and select Options .
Select Call to call to the sender. You can delete conversations, and add the sender to a screened list. You can also access Message settings .

© 2018 HMD Global Oy. All rights reserved.

Personalize your phone

Change your ring or message tone

You can choose a new ringtone or message tone.

CHANGE YOUR RINGTONE

1. Select Menu > ⚙ > Tones .
2. Choose Ringtone .
3. Scroll to a ringtone.
4. Press OK .



Tip: Is your ringtone too loud or too silent? Select Ringtone volume and scroll left or right.

CHANGE YOUR MESSAGE TONES

1. Select Menu > ⚙ > Tones > Messages .
2. Scroll to a message tone.
3. Press OK .

Change the look of your home screen

Change the look of your home screen with display settings.

CHOOSE A NEW WALLPAPER

You can change the background of your home screen with Wallpaper setting.

© 2018 HMD Global Oy. All rights reserved.

1. Select Menu > ⚙ > Display settings > Wallpaper .
2. Select Default to see the available wallpapers.
3. Scroll to a wallpaper and select View to see how it looks on the screen.
4. Select Choose and then the option to position the wallpaper on the screen.

You can also select a wallpaper from the photos you have on your phone.

CHANGE THE FONT SIZE

You can change the font size on your phone to larger in Font size setting.

1. Select Menu > ⚙ > Display settings > Font size .
2. Select the application where you want to have larger font, Messaging , Contacts , or Menu .
3. Scroll to the font size you want to use and select Choose .

SHOW DATE AND TIME

You can choose if you want to see date and time on the home screen of your phone.

1. Select Menu > ⚙ > Date and time > Show date and time .
2. Select On to have them visible on the home screen.

If you want your phone to have time updated automatically, set Auto-update time to On .

OTHER DISPLAY SETTINGS

You can edit other display settings too. You can set them on or off and change their features, such as time-out and intensity.

Profiles

Your phone has different profiles for different situations. You can edit the profiles to your liking.

© 2018 HMD Global Oy. All rights reserved.

PERSONALIZE PROFILES

There are several profiles that you can use in different situations. There is, for example, a silent profile for when you cannot have sounds on, and an outdoor profile with loud tones.

You can personalize profiles further.

1. Select Menu > ⚙ > Profiles .
2. Select a profile and Personalise .

For each profile you can set a specific ringtone, ringtone volume, message sounds and so on.



Tip: You can add different profiles to Go to menu for quick access.

Settings for Go to

You can add quick links to different applications and settings to Go to .

EDIT GO TO SETTINGS

On the bottom left-hand corner you have Go to , and when you select it, you can access different applications and settings. You can change the applications and settings to your liking.

1. Select Menu > ⚙ > Go to settings .
2. Select Choose options .
3. Scroll to a shortcut you want to add on the Go to list on the home screen and Mark them.
4. Select Done to exit the list, and Yes to save changes.

You can also reorganize your Go to list.

1. Select Organise .
2. Scroll to an item you want to move and select Move .

© 2018 HMD Global Oy. All rights reserved.

3. Select if you want to move it up, down, to top, or to bottom of the list.
4. Select Back to exit the list, and Yes to save changes.

© 2018 HMD Global Oy. All rights reserved.

Camera

Photos

You don't need a separate camera when your phone has all you need for capturing memories.

TAKE A PHOTO

Capture the best moments with your phone camera.

1. To switch the camera on, select Menu > .
2. To zoom in or out, scroll up or down.

3. To take a photo, select .



Tip: To take a selfie, select Selfie > .



Tip: To switch the flash on, in camera, select > Flash on .

VIEW A PHOTO YOU HAVE TAKEN

To view the photo right after taking it, select New > > Photos > Captured . To view the photo later, in camera, select > Photos > Captured .

© 2018 HMD Global Oy. All rights reserved.

Videos

You don't need a separate video camera - record video memories with your phone.

RECORD A VIDEO

Besides taking photos, you can also record videos with your phone.

1. To switch the camera on select Menu > .
2. To switch the video camera on, select > Video camera .
3. To start recording, select .
4. To stop recording, select .



Tip: Need more space for your videos? Insert a memory card, and your videos are saved directly to the card.

WATCH THE RECORDED VIDEO

To view the video right after recording, select .



Tip: To view the video later, select Menu > > Recorded .

© 2018 HMD Global Oy. All rights reserved.

Internet and connections

Browse the web

Learn how to browse the web with your phone.

CONNECT TO INTERNET

Catch up on the news, and visit your favorite websites on the go.

1. Select Menu > > Surf or search .
2. Write a web address, and select OK .



Tip: If you want to avoid data costs, switch mobile data off when you are not surfing the web. In your single SIM phone, select Menu > > Connectivity > Mobile data , and switch Mobile data connection to Off .



Tip: If you want to avoid data costs, switch mobile data off when you are not surfing the web. In your dual SIM phone, select Menu > > Connectivity > Dual SIM , and switch Mobile data connection to Off .

© 2018 HMD Global Oy. All rights reserved.

Music and videos

Music player

You can listen to your MP3 music files with the music player. To play music, you need to store the music files on a memory card.

LISTEN TO MUSIC

1. Select Menu > .
2. Select Options > All songs .
3. Select a song.

Tip: To listen to music using wireless headphones, pair your phone with a compatible Bluetooth headset (sold separately). To switch Bluetooth on, select Menu > > Connectivity > Bluetooth , and switch Bluetooth to On .

Video player

Watch your favorite videos wherever you are.

PLAY A VIDEO

1. Select Menu > .
2. Select the folder containing the video you want to watch, and then the video.

Tip: Not all video formats are supported.

© 2018 HMD Global Oy. All rights reserved.

PAUSE AND RESUME PLAYBACK

Press the scroll key, and select Pause or Play .

© 2018 HMD Global Oy. All rights reserved.

Radio

Find and save radio stations

Connect a compatible headset. It acts as an antenna.

SEARCH FOR YOUR FAVORITE RADIO STATIONS

1. Select Menu > .
2. To search for all available stations select Options > Auto tuning .
3. To switch to a saved station select Options > Stations , and scroll up or down.



Tip: To switch to a saved station, you can also press a number key.



Tip: To rename station, select the station and Options > Rename .

Listen to radio

Did you find a good radio station? Next, start listening to it!

LISTEN TO YOUR FAVORITE RADIO STATIONS ON YOUR PHONE

Select Menu > .
To change the volume, scroll up or down.
To close the radio, select Options > Turn off .

© 2018 HMD Global Oy. All rights reserved.

Clock, calendar, and calculator

Set the time and date manually

You can set your phone clock manually.

CHANGE THE TIME AND DATE

1. Select Menu > ⚙ > Date and time .
2. Switch Auto-update time to Off .
3. To set the time, scroll down, and select Time . Use the scroll key to set the time, and select OK .
4. To set the date, scroll down, and select Date . Use the scroll key to set the date, and select OK .

Alarm clock

Learn how to use the alarm clock to wake up and get to places on time.

SET AN ALARM

No clock around? Use your phone as an alarm clock.

1. Select Menu > .
2. Select an alarm and Edit > Change .
3. To set the hour, scroll up or down. To set the minutes, scroll right and then up or down.
4. Select OK > Save .

© 2018 HMD Global Oy. All rights reserved.

Calendar

Need to remember an event? Add it to your calendar.

ADD A CALENDAR REMINDER

1. Select Menu > 12.
2. Select a date and Options > Add event.
3. Type in a name for the event.
4. To set the time, scroll down, and select Change. To set the hour, scroll up or down. To set the minutes, scroll right and then up or down.
5. Select Save.



Tip: By default, you are reminded by an alarm 15 minutes before the event. To change the alarm time, scroll down, and select Change. Select a reminder or Never.

Calculator

Learn how to add, subtract, multiply and divide with your phone calculator.

HOW TO CALCULATE

1. Select Menu > %.
2. Enter the first factor of your calculation, use the scroll key to select the operation, and enter the second factor.
3. Select Equals to get the result of the calculation.

Select Clear to empty the number fields.

© 2018 HMD Global Oy. All rights reserved.

Bluetooth

Activate Bluetooth

Connect your phone with Bluetooth to other devices.

SWITCH ON BLUETOOTH

Select Menu > ⚙ > Connectivity > Bluetooth and switch Bluetooth on.

© 2018 HMD Global Oy. All rights reserved.

Copy and remove content

Copy content

Copy photos, videos, music, and other content created by you (and stored on the memory card) between your phone and computer.

COPY CONTENT BETWEEN YOUR PHONE AND COMPUTER

To copy content from the phone memory, you need to have a memory card inserted in your phone.

1. Connect your phone to a compatible computer with a compatible USB cable.
2. Select Mass storage .
3. On your computer, open a file manager, such as Windows Explorer, and browse to your phone. You can see the content stored on the memory card.
4. Drag and drop items between your phone and computer.

Share content

Share your stuff, such as contacts, photos, and videos, easily with friends and family.

SHARE YOUR CONTENT USING SLAM

Just move your phone close to another phone and your content is transferred using Bluetooth.

1. Switch Bluetooth on in the receiving phone, and make sure the phone is visible to other phones.
2. Select, for example, a photo. Press the options key, and select Share photo > Slam via Bluetooth .
3. Move your phone close to the other phone.

© 2018 HMD Global Oy. All rights reserved.

Tip: Slam searches for the nearest phone, and sends the item to it.

Operating the device in hidden mode is a safer way to avoid malicious software. Do not accept Bluetooth connection requests from sources you do not trust. You can also switch the Bluetooth function off when you are not using it.

Remove private content from your phone

If you buy a new phone, or otherwise want to dispose of or recycle your phone, here's how you can remove your personal info and content.

REMOVE CONTENT FROM YOUR PHONE

When removing private content from your phone, pay attention to whether you are removing content from the phone memory or the SIM card.

1. To remove messages, select Menu > > Options > Delete more > Options > Choose all > Done . Go to the folder you want to empty, and select Options > Delete conversation > Yes .
2. To remove contacts, select Menu > > Options > Delete contacts > Options > Choose all > Done > Delete .
3. To remove your call info, select Menu > > Clear call log > All calls .
4. Check that all your personal content has been removed.

© 2018 HMD Global Oy. All rights reserved.

Backup and restore

Create a backup

Sometimes you need to create a backup of your phone data.

CREATE A BACKUP

1. Select Menu > ⚙ > Backup > Create backup .
2. Your device tells you that creating a backup may take a while and that you should not turn the phone off while the backup is created. Select Choose if you want to create a backup.
3. A list opens where you can mark the data you want to backup. You can Mark them one by one, or select Options > Choose all .
4. Your phone tells you when the backup is created.

Restore a backup

To restore a backup of your data you need the created backup file on a memory card.

RESTORE A BACKUP

1. Select Menu > ⚙ > Backup > Restore backup .
2. Select Choose and mark the data you want to restore, and select Done .
3. Your phone restarts after restoring the backup files.

© 2018 HMD Global Oy. All rights reserved.

Settings

Call settings

You can change the call settings of your phone.

AVAILABLE CALL SETTINGS

You can edit call settings depending on a setting. You can set them to be either on or off, and check the status of the setting.
You can add phone numbers to lists to be screened or blocked in call settings.

1. Select Menu > ⚙ > Call settings .
2. Select a setting you want to change.

Phone settings

You can change your phone settings.

AVAILABLE PHONE SETTINGS

You can edit phone settings depending on a setting. You can change the language of your phone, set keyguard to be on or off, and add a welcome note.

Cost settings

You can track your costs with cost settings.

© 2018 HMD Global Oy. All rights reserved.

AVAILABLE COST SETTINGS

You can set Call trackers to be On or Off .

Accessories

You can edit the accessory settings.

ACCESSORY SETTINGS

Select the available accessory and edit its settings.

Security settings

You can edit the available security settings.

AVAILABLE SECURITY SETTINGS

You can edit the security settings depending on a setting. You can set them to be either on or off, and check the status of the setting.

You can add phone numbers to a list to be blocked and create a closer user group.

1. Select Menu > ⚙ > Security settings > Change codes .
2. Select the code you want to change, either Change security code or Change barr. password .

Feedback

You can send feedback on your phone.

© 2018 HMD Global Oy. All rights reserved.

SEND FEEDBACK

You can send feedback on your phone directly from Settings.

1. Select Menu > ⚙ > Feedback.
2. Give feedback to questions as instructed, and select Send.

Restore factory settings

You can restore factory settings in this setting. Be careful, however, since you lose all personalization and all data you have added on the phone.

RESET YOUR PHONE

Accidents may happen and your phone may stop responding. You can restore the original factory settings, but be careful, since this reset removes all data you have saved in the phone memory and all your personalization.

If you are disposing your phone, note that you are responsible of removing all private content.

You need the have the security code to restore the original settings. To reset your phone to its original settings and to remove all your data, on the home screen, type in *#7370#.

1. Select Menu > ⚙ > Rest. factory settings.
2. Enter the security code. There is no more confirmation after you select OK, but the phone is reset and all data is removed.

Message settings

You can edit the message settings.

© 2018 HMD Global Oy. All rights reserved.

MESSAGE SETTINGS

Select Menu > > Options > Message settings .

You can edit general message settings, and settings for text messages, MMS messages and operator messages separately.



Tip: You can change the text font larger in messages in Messaging application. Select Options > Message settings > General settings > Larger font .

© 2018 HMD Global Oy. All rights reserved.

Product and safety information

For your safety

Read these simple guidelines. Not following them may be dangerous or against local laws and regulations. For further info, read the complete user guide.



SWITCH OFF IN RESTRICTED AREAS

Switch the device off when mobile phone use is not allowed or when it may cause interference or danger, for example, in aircraft, in hospitals or near medical equipment, fuel, chemicals, or blasting areas. Obey all instructions in restricted areas.



ROAD SAFETY COMES FIRST

Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.

© 2018 HMD Global Oy. All rights reserved.



INTERFERENCE

All wireless devices may be susceptible to interference, which could affect performance.



QUALIFIED SERVICE

Only qualified personnel may install or repair this product.



BATTERIES, CHARGERS, AND OTHER ACCESSORIES

Use only batteries, chargers, and other accessories approved by HMD Global Oy for use with this device. Do not connect incompatible products.

© 2018 HMD Global Oy. All rights reserved.



KEEP YOUR DEVICE DRY

If your device is water-resistant, please refer to its IP rating for more detailed guidance.



PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.



© 2018 HMD Global Oy. All rights reserved.

SAR

This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 0.2 inches (5 mm) away from the body. The specific maximum SAR values can be found in the Certification Information (SAR) section of this user guide. For more info, go to www.sar-tick.com.

When a carry case, belt clip or other form of device holder is used for body-worn operation, it should not contain metal and should provide at least the above-stated separation distance from the body. Note that mobile devices may be transmitting even if you are not making a voice call.

Network services and costs

Using some features and services, or downloading content, including free items, require a network connection. This may cause the transfer of large amounts of data, which may result in data costs. You may also need to subscribe to some features.

You can only use your device on the GSM 900/1800 networks. You need a subscription with a service provider.

Emergency calls

Important: Connections in all conditions cannot be guaranteed. Never rely solely on any wireless phone for essential communications like medical emergencies.

Before making the call:
- Switch the phone on.
- If the phone screen and keys are locked, unlock them.
- Move to a place with adequate signal strength.

1. Press the end key repeatedly, until the home screen is shown.
2. Type in the official emergency number for your present location. Emergency call numbers vary by location.
3. Press the call key.
4. Give the necessary info as accurately as possible. Do not end the call until given permission to do so.

© 2018 HMD Global Oy. All rights reserved.

You may also need to do the following:

- Put a SIM card in the phone.
- If your phone asks for a PIN code, type in the official emergency number for your present location, and press the call key.
- Switch the call restrictions off in your phone, such as call barring, fixed dialling, or closed user group.

Take care of your device

Handle your device, battery, charger and accessories with care. The following suggestions help you keep your device operational.

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that corrode electronic circuits.
- Do not use or store the device in dusty or dirty areas.
- Do not store the device in high temperatures. High temperatures may damage the device or battery.
- Do not store the device in cold temperatures. When the device warms to its normal temperature, moisture can form inside the device and damage it.
- Do not open the device other than as instructed in the user guide.
- Unauthorized modifications may damage the device and violate regulations governing radio devices.
- Do not drop, knock, or shake the device or the battery. Rough handling can break it.
- Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not paint the device. Paint can prevent proper operation.
- Keep the device away from magnets or magnetic fields.
- To keep your important data safe, store it in at least two separate places, such as your device, memory card, or computer, or write down important info.

During extended operation, the device may feel warm. In most cases, this is normal. To avoid getting too warm, the device may automatically slow down, close apps, switch off charging, and if necessary, switch itself off. If the device is not working properly, take it to the nearest authorised service facility.

© 2018 HMD Global Oy. All rights reserved.

Recycle



Always return your used electronic products, batteries, and packaging materials to dedicated collection points. This way you help prevent uncontrolled waste disposal and promote the recycling of materials. Electrical and electronic products contain a lot of valuable materials, including metals (such as copper, aluminum, steel, and magnesium) and precious metals (such as gold, silver, and palladium). All materials of the device can be recovered as materials and energy.

Crossed-out wheelie bin symbol



CROSSED-OUT WHEELIE BIN SYMBOL

The crossed-out wheelie bin symbol on your product, battery, literature, or packaging reminds you that all electrical and electronic products and batteries must be taken to separate collection at the end of their working life. Do not dispose of these products as unsorted municipal waste: take them for recycling. For info on your nearest recycling point, check with your local waste authority.

© 2018 HMD Global Oy. All rights reserved.

Battery and charger information

BATTERY AND CHARGER

Use your device only with an original BL-4UL rechargeable battery.

Charge your device with AC-18 charger. Charger plug type may vary.

HMD Global may make additional battery or charger models available for this device.

Battery type: BL-4UL

Single SIM
- Theoretical talk time up to 22.1 hours
- Theoretical standby time up to 31 days

Dual SIM
- Theoretical talk time up to 22.1 hours.
- Theoretical standby time up to 25.3 days

BATTERY AND CHARGER SAFETY INFO

To unplug a charger or an accessory, hold and pull the plug, not the cord.

When your charger is not in use, unplug it. If left unused, a fully charged battery will lose its charge over time.

Always keep the battery between 59°F and 77°F (15°C and 25°C) for optimal performance. Extreme temperatures reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily. Accidental short-circuiting can happen when a metallic object touches the metal strips on the battery. This may damage the battery or the other object.

Do not dispose of batteries in a fire as they may explode. Obey local regulations. Recycle when possible. Do not dispose as household waste.

© 2018 HMD Global Oy. All rights reserved.

Do not dismantle, cut, crush, bend, puncture, or otherwise damage the battery in any way. If a battery leaks, do not let liquid touch skin or eyes. If this happens, immediately flush the affected areas with water, or seek medical help. Do not modify, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids. Batteries may explode if damaged.

Use the battery and charger for their intended purposes only. Improper use, or use of unapproved or incompatible batteries or chargers may present a risk of fire, explosion, or other hazard, and may invalidate any approval or warranty. If you believe the battery or charger is damaged, take it to a service centre or your phone dealer before continuing to use it. Never use a damaged battery or charger. Only use the charger indoors. Do not charge your device during a lightning storm.

Small children

Your device and its accessories are not toys. They may contain small parts. Keep them out of the reach of small children.

Medical devices

Operation of radio transmitting equipment, including wireless phones, may interfere with inadequately shielded medical devices' function. Consult a physician or the medical device's manufacturer to determine if it is adequately shielded from external radio energy.

Implanted medical devices

To avoid potential interference, manufacturers of implanted medical devices recommend a minimum separation of 15.3 centimeters (6 inches) between a wireless device and the medical device. Persons who have such devices should:

- Always keep the wireless device more than 15.3 centimeters (6 inches) from the medical device.
- Not carry the wireless device in a breast pocket.
- Hold the wireless device to the ear opposite the medical device.
- Switch the wireless device off if there is any reason to suspect that interference is taking place.

© 2018 HMD Global Oy. All rights reserved.

- Follow the manufacturer directions for the implanted medical device.

If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

Hearing



Warning: When you use the headset, your ability to hear outside sounds may be affected. Do not use the headset where it can endanger your safety.

Some wireless devices may interfere with some hearing aids.

Protect your device from harmful content

Your device may be exposed to viruses and other harmful content. Take the following precautions:

- Be cautious when opening messages. They may contain malicious software or otherwise be harmful to your device or computer.
- Be cautious when accepting connectivity requests, browsing the internet, or downloading content. Do not accept Bluetooth connections from sources you do not trust.
- Only install and use services and software from sources that you trust and that offer adequate security and protection.
- Install antivirus and other security software on your device and any connected computer. Only use one antivirus app at a time. Using more may affect performance and operation of the device and/or computer.
- If you access preinstalled bookmarks and links to third party internet sites, take the appropriate precautions. HMD Global does not endorse or assume liability for such sites.

© 2018 HMD Global Oy. All rights reserved.

Vehicles

Radio signals may affect improperly installed or inadequately shielded electronic systems in vehicles. For more info, check with the manufacturer of your vehicle or its equipment.
Only qualified personnel should install the device in a vehicle. Faulty installation may be dangerous and invalidate your warranty. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable or explosive materials in the same compartment as the device, its parts, or accessories. Do not place your device or accessories in the air bag deployment area.

Potentially explosive environments

Switch your device off in potentially explosive environments, such as near gasoline pumps. Sparks may cause an explosion or fire resulting in injury or death. Note restrictions in areas with fuel; chemical plants; or where blasting operations are in progress. Areas with a potentially explosive environment may not be clearly marked. These usually are areas where you are advised to switch your engine off, below deck on boats, chemical transfer or storage facilities, and where the air contains chemicals or particles. Check with the manufacturers of vehicles using liquefied petroleum gas (such as propane or butane) if this device can be safely used in their vicinity.

Certification information (SAR)

This mobile device meets guidelines for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields), recommended by international guidelines from the independent scientific organization ICNIRP. These guidelines incorporate substantial safety margins that are intended to assure the protection of all persons regardless of age and health. The exposure guidelines are based on the Specific Absorption Rate (SAR), which is an expression of the amount of radio frequency (RF) power deposited in the head or body when the device is transmitting. The ICNIRP SAR limit for mobile devices is 2.0

© 2018 HMD Global Oy. All rights reserved.

W/kg averaged over 10 grams of tissue.

SAR tests are carried out with the device in standard operating positions, transmitting at its highest certified power level, in all its frequency bands.

This device meets RF exposure guidelines when used against the head or when positioned at least 5/8 inch (1.5 centimetres) away from the body. When a carry case, belt clip or other form of device holder is used for body-worn operation, it should not contain metal and should provide at least the above stated separation distance from the body.

To send data or messages, a good connection to the network is needed. Sending may be delayed until such a connection is available. Follow the separation distance instructions until the sending is finished.

During general use, the SAR values are usually well below the values stated above. This is because, for purposes of system efficiency and to minimise interference on the network, the operating power of your mobile is automatically decreased when full power is not needed for the call. The lower the power output, the lower the SAR value.

Device models may have different versions and more than one value. Component and design changes may occur over time and some changes could affect SAR values.

For more info, go to www.sar-tick.com. Note that mobile devices may be transmitting even if you are not making a voice call.

The World Health Organization (WHO) has stated that current scientific information does not indicate the need for any special precautions when using mobile devices. If you are interested in reducing your exposure, they recommend you limit your usage or use a hands-free kit to keep the device away from your head and body. For more information and explanations and discussions on RF exposure, go to the WHO website at www.who.int/peh-emf/en.

© 2018 HMD Global Oy. All rights reserved.

Copyrights and other notices

DECLARATION OF CONFORMITY

Hereby, HMD Global Oy (Ltd.) declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EC. A copy of the Declaration of Conformity can be found at www.nokia.com/mobile-declaration-of-conformity.

The availability of products, features, apps and services may vary by region. For more info, contact your dealer or your service provider.

This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. HMD Global reserves the right to revise this document or withdraw it at any time without prior notice.

To the maximum extent permitted by applicable law, under no circumstances shall HMD Global or any of its licensors be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

Reproduction, transfer or distribution of part or all of the contents in this document in any form without the prior written permission of HMD Global is prohibited. HMD Global operates a policy of continuous development. HMD Global reserves the right to make changes and improvements to any of the products described in this document without prior notice.

HMD Global does not make any representations, provide a warranty, or take any responsibility for the functionality, content, or end-user support of third-party apps provided with your device. By using an app, you acknowledge that the app is provided as is.

Downloading of maps, games, music and videos and uploading of images and videos

© 2018 HMD Global Oy. All rights reserved.

may involve transferring large amounts of data. Your service provider may charge for the data transmission. The availability of particular products, services and features may vary by region. Please check with your local dealer for further details and availability of language options.

Certain features, functionality and product specifications may be network dependent and subject to additional terms, conditions, and charges. All are subject to change without notice.

Manufacturer and/or importer in EU: HMD Global Oy, Karaportti 2, 02610 Espoo, Finland.

HMD Global Privacy Policy, available at www.nokia.com/en{underscore, applies to your use of the device.

© 2017 HMD Global. All rights reserved. HMD Global Oy is the exclusive licensee of the Nokia brand for phones & tablets. Nokia is a registered trademark of Nokia Corporation.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by HMD Global is under license.

This product includes open source software. For applicable copyright and other notices, permissions, and acknowledgements, select *#6774# on the home screen.

About Digital Rights Management

When using this device, obey all laws and respect local customs, privacy and legitimate rights of others, including copyrights. Copyright protection may prevent you from copying, modifying, or transferring photos, music, and other content.

© 2018 HMD Global Oy. All rights reserved.

Frequently asked questions

How do I get help for my phone?

Have a look at our user guides first. If you still can't find what you're looking for, get in touch with your network provider or the store where you bought your phone.

Where can I find the warranty terms for my phone?

Have a look at the user guide that came with your phone, or you can get in touch with your network provider or the store you bought your phone from.

How do I get my phone repaired or replaced?

We offer replacement phones rather than repairs. In case your phone is defective, your network provider or the store you bought your phone from will be able to help getting you a replacement device.

What should I do if my phone is lost or stolen?

Contact your network provider right away and tell them it's missing. If your phone is stolen, you should also report it to the police immediately.

Where can I see the full range of Nokia phones?

Head here to see our latest mobile phones. Most mobile phone operators and retailers will also have all or some of the Nokia range available.

© 2018 HMD Global Oy. All rights reserved.

Where can I buy a Nokia phone?

You can buy a Nokia phone from most mobile phone operators and retailers.

My phone won't turn on, what should I do?

Charge your device for at least 10-30 minutes and then try turning it on. If that doesn't work you should contact your network provider or the store you bought it from.

My phone won't charge, what should I do?

First, make sure the socket you're using is providing power by plugging another device in. Next check the power cable for any damage. Do the same with your phone's charging port and remove any debris that might be stuck in it. Once you've checked everything's OK, turn your phone off and plug it in – if the battery is completely drained it may take 2-3 minutes to start charging. If that doesn't work, get in touch with your network provider or the store you bought it from.

Troubleshooting tips

If you're having problems with your phone, it's always worth trying one of the following to see if it helps:

Restart your phone

Turn your phone off and take the battery out. Wait a 30 seconds put the battery back in and then switch your phone on.

Charge your phone

Once the battery is full, disconnect the charger and try restarting your phone.

© 2018 HMD Global Oy. All rights reserved.

If the battery is completely discharged, it may take several minutes before the charging indicator is shown or before you can make any calls. If the battery has not been used for a long time, you may need to connect and disconnect the charger a couple of times.

Restore the factory settings

If your phone isn't working properly you can try resetting it. This does not affect documents or files stored on your phone but **we recommend you back it up first before restoring to factory settings, just in case.**(⚙ > Backup).

1. End all calls and connections
2. Go to Menu > ⚙ > Restore Factory Settings > Settings only
3. Type in your passcode

After restoring the original settings, your phone switches off and then on again. This may take longer than usual.

Where can I get support for my Lumia smartphone?

There are two main resources that provide support for Lumia phones. For general support and information, you can visit Microsoft Mobile devices help page. For troubleshooting and repair queries, you can visit B2X and search for your Lumia model.

© 2018 HMD Global Oy. All rights reserved.